


MAGIC SNACK 60


ELETTRICO / ELECTRIC / ELEKTRO / ELECTRIQUE

PC-61EM PC-62EM PC-62ET N°≥0310

	1
Vedi Pagina See Page Siehe Seite Voir Page Ver Página	130



PC-E



Page	Pos	Code	Description
001		541015500	NEUTRAL SPACER 62
001		537002200	ELECTRICAL PLATE D.180 W1500 V230
001		537002100	ELECTRICAL PLATE D.145 W1000 V230
001		544060502	UPPER PLATE NEW PC-62E CF-62E
001		537007600	TERMINAL BLOCK SINGLEPHASE 40A
001		544062000	LEFT SIDE PANEL 60 LINE
001		536006900	RUBBER CABLE GUIDE D.25MM.HOLE 16MM
001		544022600	CONTROL PANEL PC-2E
001		533010300	ADJUSTABLE FOOT M10*20 D.23
001		544061900	RIGHT SIDE PANEL 60 LINE
002		537000300	COMMUTATOR 7 POSITIONS S.49 16A
002		536002100	KNOB 7 POSITIONS SNACK
002		537014100	WHITE WARNING LIGHT 250V