Electrolux


SPARE PARTS CATALOGUE
CATALOGO PARTI DI RICAMBIO


06 GN 1/1 GAS CONVECTION / STEAM OVEN
FORNO CONVEZIONE / VAPORE GAS 06 GN 1/1


PNC	Model	Ref	Group	Level	Page	Notes
646570	HOR061GKG	o	DIA	Level K	2...11	230V 50Hz DIAMOND
646700	FCZ061GKGN	q	To brand	Level K	2...11	230V 50Hz To brand
646730	**HOR061GKZN**	**w**	**DIA**	**Level K**	**2...11**	**230V 50Hz DIAMOND AUS**
647500	EJN061GAG	a	EJN	Level A	2...11	230V 50Hz STD
647510	EJN061GAD	b	EJN	Level A	2...11	230V 50Hz LPG
647540	RDR061GAG	c	RDR	Level A	2...11	230V 50Hz STD
647570	HOR061GAG	d	HOR	Level A	2...11	230V 50Hz STD
647700	FCZ061GTGN	r	To brand	Touch	2...11	230V 50Hz To brand
647720	HOR061GTGN	t	DIA	Touch	2...11	230V 50Hz DIAMOND
647730	**HOR061GTZN**	**v**	**DIA**	**Touch**	**2...11**	**230V 50Hz DIAMOND AUS**
648500	EJN061GBG	e	EJN	Level B	2...11	230V 50Hz STD
648510	EJN061GBD	f	EJN	Level B	2...11	230V 50Hz LPG
648540	RDR061GBG	g	RDR	Level B	2...11	230V 50Hz STD
648570	HOR061GBG	h	HOR	Level B	2...11	230V 50Hz STD
648700	FCZ061GBGN	s	To brand	Level B	2...11	230V 50Hz To brand
648710	FCZ061GBGE	p	EMP	Level B	2...11	230V 50Hz EMPERO
648720	HOR061GBGN	u	DIA	Level B	2...11	230V 50Hz DIAMOND
649500	EJN061GCG	i	EJN	Level C	2...11	230V 50Hz STD
649510	EJN061GCD	l	EJN	Level C	2...11	230V 50Hz LPG
649540	RDR061GCG	m	RDR	Level C	2...11	230V 50Hz STD
649570	HOR061GCG	n	HOR	Level C	2...11	230V 50Hz STD
649730	**HOR061GCZN**	**z**	**DIA**	**Level C**	**2...11**	**230V 50Hz DIAMOND AUS**

Pag	Index	Indice	Note
2	Oven cabinet and door.	Cella forno e porta	
3	Water system	Impianto idraulico	
4	Boiler	Boiler	
5	Electrical components	Componenti elettrici	
6	Accessories	Accessori	
7...11	Spare parts list	Lista ricambi	


Brand/Marchio: All
Factory code: 9PDD



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
26
27
28
29
30
31
32
33
34
35
36
37
38
41
42
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
61
62
62new
64
65
66
67
68


117
118
119
139
120
121
122
147
116
145
129
145
137
132
138
131
134
133
100
101
102
103
102
104
106
107
108
109
110
144
130
141a
143
141
146
142
140
105
NEW
135
125
124
127
126
123
136



	AERATORE/AERATOR		DIAFRAMMA/DIAPHRAGM	
GAS	POS. A1 CELLA/CAVITY	POS. A1 BOILER	POS. A2 CELLA/CAVITY	POS. A2 BOILER
G20	0C4630 (FUCSIA/FUCHSIA)	0C4630 (FUCSIA/FUCHSIA)	0C2445 (ø 6)	0C2445 (ø 6)
G25	0C4630 (FUCSIA/FUCHSIA)	0C4630 (FUCSIA/FUCHSIA)	0C5235 (ø 6,75)	0C5235 (ø 6,75)
G30	0C4630 (FUCSIA/FUCHSIA)	0C4630 (FUCSIA/FUCHSIA)	0C4383 (ø 5.25)	0C4384 (ø 4,75)
LPG	0C4630 (FUCSIA/FUCHSIA)	0C4630 (FUCSIA/FUCHSIA)	0C2442 (ø 5.5)	0C4385 (ø 5)


317
332
336
318
314
316
315
313
319
331
321
320
312
324
323
322
311
330
341
329
308
309
307
325
326
327
305
304
328
302
300
303
301
340
307
305
304
337
338
339
343
342


400
401
403
402
404
405
406

Electrolux

SPARE PARTS CATALOGUE
CATALOGO PARTI DI RICAMBIO


CATALOGO RICAMBI PER DOCCETTA

0C4248

SPARE PART LIST FOR

0C4248

SPRAY HOSE REEL


1
2
3
4
5
6
7
8
9
10
11
12
14