


Pelatore universale-pelapatate-lavacozze mod. PLN-PPN-LCN10-18
Universal peeler-potato peeler-mussel washer mod. PLN-PPN-LCN10-18



PELATORE UNIVERSALE-PELATATATE-LAVACOZZE MOD.PLN-PPN-LCN10-18
UNIVERSAL PEELER-POTATO PEELER-MUSSEL WASHER MOD.PLN-PPN-LCN10-18

Rif No	Codice Code		Caratteristiche Characteristics	Descrizione Description	
1	36G6590			Albero Shaft	
2	3151300		28x42x7	Paraolio Oil seal	
3	3190830			Rosetta Washer	
4	36F0090		6302 2RS	Cuscinetto Bearing	
5	36G5950			Boccola Bush	
6	3600870			Fondo Bottom	
7	3151750			Guarnizione Gasket	
8	36G6600			Puleggia Pulley	
9	36G6610	☺	Poly V-559 j12	Cinghia Belt	
10	36G6620		(PLN-PPN10-18)	Puleggia Pulley	
10	36G0030		(LCN10-18)	Puleggia Pulley	
11	35V1230			Staffa Bracket	
12	SL0010		5x5x20	Linguetta Key	
13	SL0040		400V/3Ph/50Hz (PPN10)	Motore Motor	
13	SL0041		230V/1Ph/50Hz (PPN10)	Motore Motor	
13	SL1041		400V/3Ph/50Hz (PPN18)	Motore Motor	
13	SL1042		230V/1Ph/50Hz (PPN18)	Motore Motor	
13	SL1521		400V/3Ph/50Hz (LCN10)	Motore Motor	
13	SL1523		230V/1Ph/50Hz (LCN10)	Motore Motor	
13	SL1522		400V/3Ph/50Hz (LCN18)	Motore Motor	
13	SL1524		230V/1Ph/50Hz (LCN18)	Motore Motor	
13	32M4080		400V/3Ph/50Hz (PLN10)	Motore Motor	
13	32M4050		400V/3Ph/50Hz (PLN18)	Motore Motor	
14	3140460		ø88+ø96	Fascetta Clip	
15	SL2721		ø90 (PLN-PPN-LCN)	Tubo Tube	
15	35X1150		ø90 (PLF-PPF-LCF)	Tubo Tube	
16	3151550		ø15xø25x3	Guarnizione Gasket	
17	33M0010		3/4" F-F	Tubo Tube	
18	33D1371	☺	230V/50-60Hz 3/4" M	Elettrovalvola Electro-valve	
19	SL0893		PG13,5	Pressacavo Cable clamp	
19	32D0360		01/01/04 f.p.(*)	Pressacavo Cable clamp	
20	32D1090		PG21	Pressaquaina Sheathing clamp	
21	SL2939			Piastra Plate	
21	35Q8620		01/01/04 f.p.(*)	Piastra Plate	
22	SL2785			Piastra Plate	
22	35V8601		01/01/04 f.p.(*)	Divisorio Dividing head	
23	32D0630		01/01/04 f.p.(*)	Piastra Plate	
24	SA3450		(PTA) plastic	Kit disco Disk set	
25	6005390		Assembly	Sportello Door	
26	35M8840			Copertura Covering	
27	SL2921	☺		Scheda elettronica Electronic card	
27	32Z4840		01/01/04 f.p.(*)	Teleruttore Remote control switch	
28	32W3240	☺		Microinterruttore Microswitch	
29	33Q6210		1/4" M-F	Raccordo Nipple	
30	33Q6040		L 90° 1/4" M-F	Raccordo Nipple	
31	33Q5180		1/4" M ø12	Portagomma Clutch	
32	33M0960		ø12	Tubo Tube	
33	36D9660			Saltarello Leaper	
34	36G2040			Perno Pivot	
35	30W2930		(PLN-PPN-LCN10)	Carcassa Housing	
35	SL2694		(PLN-PPN-LCN18)	Carcassa Housing	
35	30W3010		22/07/03f.p.(*) (PLN-PPN-LCN18)	Carcassa Housing	
36	SL2695			Fondo Bottom	
37	36C0011			Telaio Frame	
38	37Q7860	☺		Guarnizione Gasket	
39	3600160	☺		Magnete Magnet	
40	SL2494	☺		Tela abrasiva Emery cloth	
41	6005380		Assembly	Coperchio Cover	
42	SA3400		Assembly	Sportello Door	
43	36D9550			Boccola Bush	
44	SL2135			Disco Disk	
45	ACPTA		Assembly	Disco patate Potato disk	
46	ACCI		(PLF-PPF-LCF) Assembly	Telaio Frame	
47	36M5090			Maniglia Handle	
48	SL2871	☺		Guarnizione Gasket	
49	36Z6501			Coperchio Cover	
50	3600310	☺		Magnete Magnet	
51	35V6381			Staffa Bracket	
52	32Z3030		01/01/04 f.p.(*)	Scheda elettronica Electronic card	
53	30A3620			Pannello Panel	
53	30A3560		01/01/04 f.p.(*)	Pannello Panel	
54	37M4770			Etichetta Label	
54	SL1504		01/01/04f p (*) (PPN-LCN10-18)	Etichetta Label	
54	SL1505		01/01/04 f.p.(*) (PLN10-18)	Etichetta Label	
55	36D7310			Boccola Bush	
56	36Z0690			Scatola Box	
57	36G6880			Disco cozze Mussel disk	
58	36M5250			Pomello Knob	
59	6000930		Assembly	Sportello Door	
60	6005400		Assembly	Maniglia Handle	
61	ACPPC		Assembly	Disco cozze Mussel disk	
62	SL2720		ø100-ø50	Riduzione Reduction	
63	SL2719		ø50	Gomito Bend	
64	32W2970	☺	230V 2W green	Lampada Lamp	
65	32W3280	☺	230V 2W white	Lampada Lamp	
66	SL2348	☺		Timer	
67	SL1539	☺	Unstable	Pulsante Push button	

(*): fuori produzione / out of production

☺: ricambio consigliato / spare part suggested