


MAGIC PROF 65

CUCINE / RANGES / HERDE / CUISINIÈRES / N° ≥0309

CF...-8...

CF4-8ET CF4-8ETS

	1CF4-8ET	1CF4-8ETS	2	3
Vedi Pagina See Page Siehe Seite Voir Page Ver Pàgina	82	80	86	90




MAGIC PROF 65

CUCINE / RANGES / HERDE / CUISINIÈRES / N° ≥0309

FORNO / OVEN / BACKOFEN / FOUR

STATICO ELETTRICO / TRADITIONAL ELECTRIC / STATISCHER ELEKTRO /
ELECTRIQUE STATIQUE ≤0705




MAGIC PROF 65


CUCINE / RANGES / HERDE / CUISINIÈRES / N° ≥ 0309

FORNO / OVEN / BACKOFEN / FOUR

PORTE / DOORS / TÜREN / PORTES ≤ 0705



CF



Page	Pos	Code	Description
001		537002300	ELECTRICAL PLATE D.220 W2000 V230
001		544263500	RIGHT SIDE S.65
001		544257400	UPPER PLATE PC-8E
001		544293600	CONTROL PANEL CF4/CFC4-8ET
001		544302101	CONTROL PANEL CF4/CFC4-8ETS * NEW
001		539018900	INDEX FOR KNOB
001		539018100	ADHESIVE GRADUATED DISC FOR KNOB
001		537000300	COMMUTATOR 7 POSITIONS S.49 16A
001		544263600	LEFT SIDE S.65
001		537007700	TERMINAL BLOCK THREEPHASE 40A
001		57014100	
001		536013800	KNOB D.70 BLACK 6*5 WITH SPRING
002		537001600	THERMOSTAT 50-320°C SINGLEPHASE
002		537014100	WHITE WARNING LIGHT 250V
002		537005700	OVEN COMMUTATOR CF-8/10 EL.
002		539023900	SIGN PLATE FOR OVEN TEMPERATURE
002		537005400	OVEN BULB 15W 300°C
002		536013800	KNOB D.70 BLACK 6*5 WITH SPRING
002		539023100	ADHESIVE GRADUATED DISC FOR MAXI OV
002		537014200	GREEN WARNING LIGHT 250V
002		533037600	LOCK SPRING FOR BULB
002		537006200	UPPER OVEN HEATING EL.1000+2000W
002		537007900	OVEN BULB-SOCKET
002		536011300	OVEN GASKET CF-8/10
002		531012401	OVEN DOOR WHEEL HOLDER F.CF-8/10
002		531006700	OVEN GRID FOR CF-8/10
002		534002200	OVEN DRIPPING-PAN CF-8/10
002		531013600	SIDE GRID FOR MAXI/VENTILATED OVEN
002		537006300	LOWER OVEN HEATING EL.W1750 230CF8/
002		534009100	GRILL PROTECTION CF-8/10
002		534009101	
003		531009601	COMPLETE GLASS OVEN DOOR
003		544015900	INNER GLASSDOOR OF MAXI OVEN
003		544015901	INNER-DOOR FOR MAXI OVEN *GLASS*
003		536007100	INTERNAL GLASS OVEN DOOR CF-8/10
003		536007101	
003		536021800	DOOR HANDLE SPACER FOR MAXI OVEN
003		531007001	OVEN GLASS DOOR HANDLE CF-8/10
003		536007001	EXTERNAL GLASS OVEN DOOR CF8/10
003		531007301	DOOR HINGE FOR MAXI OVEN CF-8/10
003		531012701	STAINLESS STEEL OVEN DOOR 60/65LINE
003		544015700	INNER DOOR OF MAXI OVEN
003		544015701	INNER-DOOR FOR MAXI OVEN
003		544074701	S/S MAXI OVEN DOOR PANEL
003		544074702	
004		544301600	RIGHT SIDE FOR 65 RANGE
004		544301500	LEFT SIDE FOR 65 RANGE
004		536005300	PLASTIC LED 2"