


IPERLOTUS 90 TOP

ELETTRICO / ELECTRIC / ELEKTRO / ELECTRIQUE

FTT..-94ET FTT..-98ET



560064000M00P00.

Page	Pos	Code	Description
001		541123900	UPPER PLATE FTLR-98E
001		544023800	
001		544413700	SPLASH GUARD FT-98
001		541104300	CONTROL PANEL FT-78E
001		537025200	HEATING ELEMENT W2000 V230 FT 90
001		544023901	SPATTLE FOR FRY-TOP
001		537012800	SAFETY THERMOSTAT 420°C THREEPHASE
001		541096400	DRIP TRAY FT S.70
001		539018400	ADHESIVE GRADUATED DISC FOR KNOB
001		536019700	BLACK KNOB §70 PIN §6*5
001		537000200	COMMUTATOR 1 POS. 3PHASE S.49 16A
001		539018900	INDEX FOR KNOB
001		537001200	FIXING BRACKET FOR THERMOSTAT/COMM.
001		537000900	THERMOSTAT 50-320°C THREEPHASE
001		537014200	GREEN WARNING LIGHT 250V
001		537014100	WHITE WARNING LIGHT 250V
001		544446900	
001		544446800	
001		533010500	LEG M10*25 D.40
001		537007700	TERMINAL BLOCK THREEPHASE 40A
001		532004100	FLUE GRID L=370 70LINE (RAF)