


**Macchina sottovuoto mod.MSV300-400-500 MSE400**  
**Vacuum packaging machine mod.MSV300-400-500 MSE400**



**MACCHINA SOTTOVUOTO MOD.MSV300-400-500 MSE400**  
**VACUUM PACKAGING MACHINE MOD.MSV300-400-500 MSE400**

RIF.	CODICE / CODE	DIN - UNI	DESCRIZIONE / DESCRIPTION
1	CO1363		Carcassa mod.MSV300 / Housing mod.MSV300
1	CO1364		Carcassa mod.MSV400 / Housing mod.MSV400
1	CO1365		Carcassa mod.MSE400 / Housing mod.MSE400
1	CO1366		Carcassa mod.MSV500 / Housing mod.MSV500
2	CO1367		Copertura mod.MSV300 / Cover mod.MSV300
2	CO1368		Copertura mod.MSV400 / Cover mod.MSV400
2	CO1369		Copertura mod.MSE400 / Cover mod.MSE400
2	CO1370		Copertura mod.MSV500 / Cover mod.MSV500
3	CO1371		Copertura mod.MSV300 / Cover mod.MSV300
3	CO1372		Copertura mod.MSV-MSE400 / Cover mod.MSV-MSE400
3	CO1373		Copertura mod.MSV500 / Cover mod.MSV500
4	CO1374		Leva mod.MSV-MSE400 / Lever mod.MSV-MSE400
5	CO1375		Leva mod.MSV500 / Lever mod.MSV500
6	CO1376	230V/1Ph/50-60Hz	Pompa mod.MSV300 / Pump mod.MSV300
6	CO1452	230V/1Ph/50-60Hz	Pompa mod.MSV-MSE400 / Pump mod.MSV-MSE400
6	CO1450	230V/1Ph/50-60Hz	Pompa mod.MSV500 / Pump mod.MSV500
7	CO1377	230V/1Ph/50-60Hz	Trasformatore mod.MSV300-MSE400 / Transformer mod.MSV300-MSE400
7	CO1378	230V/1Ph/50-60Hz	Trasformatore mod.MSV400 / Transformer mod.MSV400
7	CO1170	230V/1Ph/50-60Hz	Trasformatore mod.MSV500 / Transformer mod.MSV500
8	CO1379	230V/1Ph/50-60Hz	Scheda elettronica mod.MSV300 / Electronic card mod.MSV300
8	CO1380	230V/1Ph/50-60Hz	Scheda elettronica mod.MSE400 / Electronic card mod.MSE400
8	CO1453	230V/1Ph/50-60Hz	Scheda elettronica mod.MSV400-500 / Electronic card mod.MSV400-500
9	CO1381		Filtro mod.MSV300 / Filter mod.MSV300
9	CO1382		Filtro mod.MSV400 / Filter mod.MSV400
10	CO1383		Elettrovalvola mod.MSV-MSE400 / Electro-valve mod.MSV-MSE400
10	CO1171		Elettrovalvola mod.MSV500 / Electro-valve mod.MSV500
11	SL1671	1Ph+N+Gnd	Cavo elettrico monfase / Electric cable (single-phase)
12	SL0158	PG9	Pressacavo / Cable clamp
13	CO1385	5A 250V	Fusibile / Fuse
14	CO1384		Portafus bile / Fuse-case
15	CO1386		Microinterruttore / Microswitch
16	CO1387		Barra saldante mod.MSV300 / Seal bar mod.MSV300
16	CO1388		Barra saldante mod.MSV400 / Seal bar mod.MSV400
16	CO1389		Barra saldante mod.MSE400 / Seal bar mod.MSE400
16	CO1390		Barra saldante mod.MSV500 / Seal bar mod.MSV500
17	CO1391		Camera mod.MSV300 / Container mod.MSV300
17	CO1392		Camera mod.MSV400 / Container mod.MSV400
17	CO1393		Camera mod.MSE400 / Container mod.MSE400
17	CO1394		Camera mod.MSV500 / Container mod.MSV500
18	CO1395		Camera mod.MSV300 / Container mod.MSV300
18	CO1396		Camera mod.MSV-MSE400 / Container mod.MSV-MSE400
18	CO1397		Camera mod.MSV500 / Container mod.MSV500
19	CO1398		Guarnizione mod.MSV300 / Washer mod.MSV300
19	CO1148		Guarnizione mod.MSV-MSE400 / Washer mod.MSV-MSE400
19	CO1149		Guarnizione mod.MSV500 / Washer mod.MSV500
20	CO1150		Barretta mod.MSV300 / Bar mod.MSV300
20	CO1151		Barretta mod.MSV-MSE400 / Bar mod.MSV-MSE400
20	CO1152		Barretta mod.MSV500 / Bar mod.MSV500
21	CO1153		Raccordo mod.MSV-MSE400-500 / Joint mod.MSV-MSE400-500
22	CO1154		Gomma mod.MSV300 / Washer mod.MSV300
22	CO1155		Gomma mod.MSV-MSE400 / Washer mod.MSV-MSE400
22	CO1156		Gomma mod.MSV500 / Washer mod.MSV500
23	CO1157		Molla mod.MSV-MSE400-500 / Spring mod.MSV-MSE400-500
24	CO1157		Molla mod.MSV-MSE400-500 / Spring mod.MSV-MSE400-500
24	CO1158		Molla mod.MSV400-500 / Spring mod.MSV400-500
25	CO1159		Valvola mod.MSV400 / Valve mod.MSV400
26	CO1167		Vacuometro mod.MSV300-400-500 / Vacuum gauge mod.MSV300-400-500
27	CO1161		Raccordo mod.MSV400 / Joint mod.MSV400
28	CO1162		Maniglia mod.MSV-MSE400-500 / Handle mod.MSV-MSE400-500
29	CO1163		Piedino mod.MSV300 / Foot mod.MSV300
29	CO1164		Piedino mod.MSV-MSE400-500 / Foot mod.MSV-MSE400-500
30	CO1165		Interruttore mod.MSV300-400-500 / Switch mod.MSV300-400-500
30	CO1166		Interruttore mod.MSE400 / Switch mod.MSE400

(\*): fuori produzione / out of production