

SUPERLOTUS 70 TOP

GAS / GAS / GAS / GAZ

FTT...-74G FTT...-76G FTT...-76G FTT...-78G

- 541097700 (L-74G)
- 541097800 (R-74G)
- 541097900 (L-74GS)
- 541098000 (R-74GS)
- 541136200 (L-76G)
- 541136300 (LR-76G)
- 541136400 (R-76G)
- 541136500 (L-76GS)
- 541136600 (LR-76GS)
- 541136700 (R-76GS)
- 541098100 (L-78G)
- 541098200 (LR-78G)
- 541098300 (R-78G)
- 541098400 (L-78GS)
- 541098500 (LR-78GS)
- 541098600 (R-78GS)

- 544181201 (74)
- 544117001 (76)
- 544181301 (78)

532004100

- 541134100 (74)
- 541135500 (76)
- 541134600 (78)

544023800 (R/LR)

531026000

544023901

541096200


544385600

541096400

544385500

- 541101401 (74)
- 541147801 (76)
- 541096101 (78)

533010500



560039300M00P00

Page	Pos	Code	Description
001		541098100	UPPER PLATE FTL-78G
001		544181301	SPLASH GUARD FT-78
001		532004100	FLUE GRID L=370 70LINE (RAF)
001		541134600	LOW SPACER 78 2 GRIDS
001		531026000	BURNER FT-4/6/8G BM-4G
001		544023901	SPATTLE FOR FRY-TOP
001		541096200	BURNER SUPPORT FT-74G FT-78G
001		544385600	LEFT SIDE OF 70T LINE
001		541096400	DRIP TRAY FT S.70
001		544385500	RIGHT SIDE OF 70T LINE
001		533010500	LEG M10*25 D.40
001		541096101	CONTROL PANEL S70/90 FT-78G FT-98G