


# SUPERLOTUS 70≥0602

## CUCINE / RANGES / HERDE / CUISINIÈRES

CF...4-78...

### CF4-78ET CFQ4-78ET

	1	2	3
Vedi Pagina See Page Siehe Seite Voir Page Ver Pàgina	188	180	193



560009301M00P00


# SUPERLOTUS 70≥0602

CUCINE / RANGES / HERDE / CUISINIÈRES


FORNO / OVEN / BACKOFEN / FOUR

## PORTE / DOORS / TÜREN / PORTES

GN 2/1



GN 3/1




# SUPERLOTUS 70≥0602

CUCINE / RANGES / HERDE / CUISINIÈRES

FORNO / OVEN / BACKOFEN / FOUR



ELETRICO / ELECTRICAL / ELEKTRO / ELECTRIQUE / GN 2/1



# SUPERLOTUS 70≥0602


CUCINE / RANGES / HERDE / CUISINIÈRES  
FORNO / OVEN / BACKOFEN / FOUR

ELETTRICO / ELECTRICAL / ELEKTRO / ELECTRIQUE / GN 2/1



560034901M00P00

**PC-E CF-E**



Page	Pos	Code	Description
001		541104501	CONTROL PANEL CF4-78E CFC4-78E C
001		537019900	PLATE D.220 W2600 V230
001		541134200	NEUTRAL LOW SPACER 78
001		544190900	UPPER PLATE PC-78E ROUND PLATE
001		544191200	UPPER PLATE PC-78E SQUARE PLATE
001		537017000	PLATE 220X220 W2600 V230
001		544173300	LEFT SIDE PANEL RANGE S.70
001		537007700	TERMINAL BLOCK THREEPHASE 40A
001		544173200	RIGHT SIDE PANEL RANGE S.70
001		536005200	INOX LEG 2" 120-180 M10
002		531013100	OVEN DOOR HANDLE OF 70/90-LINE
002		544186900	OVEN DOOR GN 2/1 S.70
002		531022800	LEFT OVEN DOOR HINGE S.70
002		544187100	OVEN INNER DOOR GN 2/1 S.70
002		531022900	HINGE DOOR WHEEL HOLDER S.70
002		531022700	RIGHT OVEN DOOR HINGE 70LINE
002		544187000	OVEN DOOR GN 3/1 S.70
002		541102300	GAS OVEN INNER DOOR GN 3/1 S.70
003		533037600	LOCK SPRING FOR BULB
003		536010800	OVEN GASKET GN 2/1 (1261)
003		531030500	LHD SUPPORT GRID FOR OVEN OF 70LINE
003		544198900	70 ELECTRICAL OVEN BOTTOM GN2/1
003		531030200	OVEN GRID GN 2/1 FOR 70 LINE
003		531030400	RHD SUPPORT GRID FOR OVEN OF 70LINE
004		537012800	SAFETY THERMOSTAT 420°C THREEPHASE
004		539018800	INDEX FOR OVEN KNOB
004		539028000	SELECTOR SIGN PLATE FOR OVEN
004		537034000	
004		536019700	BLACK KNOB §70 PIN §6*5
004		539023900	SIGN PLATE FOR OVEN TEMPERATURE
004		537000900	THERMOSTAT 50-320°C THREEPHASE
004		539027900	ADHESIV.GRADUATED DISC FOR SELECTOR
004		537014200	GREEN WARNING LIGHT 250V
004		539017900	ADHESIVE GRADUATED DISC FOR KNOB
004		537014100	WHITE WARNING LIGHT 250V
004		533023600	TAP PLUG §10 M16*1, 5CH19
004		533039300	BICONE §10
004		533010800	TUBE NUT D.10 M16*1,5
004		537025400	OVEN UPPER HEAT.EL.W700 V230 70LINE
004		537020901	HEATING ELEMENT 1200W 230V OVEN S7C
005		539018900	INDEX FOR KNOB
005		536019700	BLACK KNOB §70 PIN §6*5
005		539018100	ADHESIVE GRADUATED DISC FOR KNOB
005		537000300	COMMUTATOR 7 POSITIONS S.49 16A
005		537014100	WHITE WARNING LIGHT 250V