


# IPERLOTUS 90


ELETTRICO / ELECTRIC / ELEKTRO / ELECTRIQUE

**PC-94ET PC-98ET PC-912ET PC-916ET PCQ-94ET PCQ-98ET PCQ-912ET PCQ-916ET**

Vedi Pagina See Page Siehe Seite Voir Page Ver Pagina	<b>1</b>
	<b>124</b>



## PC-E PC-EX



560023700M00C00

Page	Pos	Code	Description
001		537017100	PLATE 300X300 W4000 V230
001		541116900	UPPER PLATE PCQ-98E CFQ4-98ET
001		532004100	FLUE GRID L=370 70LINE (RAF)
001		537017400	ELECTRICAL PLATE D.300 W3500 V230
001		541116600	UPPER PLATE PC-98E CF4-98ET
001		544407400	LEFT SIDE PANEL 70 LINE
001		541104000	CONTROL PANEL PC-78E
001		536005200	INOX LEG 2" 120-180 M10
001		537007700	TERMINAL BLOCK THREEPHASE 40A
001		544407300	RIGHT SIDE PANEL 90 LINE
002		539018100	ADHESIVE GRADUATED DISC FOR KNOB
002		536019700	BLACK KNOB §70 PIN §6*5
002		539018900	INDEX FOR KNOB
002		537027700	COMMUTATOR 7 POSITIONS S.43 32A
002		537014100	WHITE WARNING LIGHT 250V