


G2941 Cast Griddle

Fitments




Item	Spares No.	Description
1.	535810014	Splash guard
2.	535810016	Griddle plate
3.	535810015	Capping channel
4.	535810002	Rope seal
5.	535810003	Hob assembly
6.	535830006	Upper front facia assembly
7.	535830007	Lower front facia
8.	535820009	Control knob
9.	535820012	Magnetic door catch (not shown)

Item	Spares No.	Description
10.	535820011	Fat jug assembly
11.	535820013	Adjustable foot
12.	535820015	Outer side panel - LH
13.	535820016	Outer side panel - RH
14.	535810004	Outer back panel
15.	535810005	Flue panel

G2941 Cast Griddle

Controls



Item	Spares No.	Description
16.	535810017	RH/LH burner injector (nat.)
17.	535810018	Centre burner injector (nat.)
18.	535820020	Injector holder (prop.)
19.	535810019	RH/LH amal jet (prop.)
20.	535810020	Centre amal jet (prop.)
21.	535820022	Pilot burner
22.	535820023	Pilot jet (nat.)
23.	535820024	Pilot jet (prop.)
24.	535820025	Thermocouple
25.	535820026	Gas governor (nat.)
26.	535820027	Burner

Item	Spares No.	Description
27.	535820028	Burner aeration shroud
28.	535830014	Float rail assembly
29.	535820030	Pressure test nipple (not shown)
30.	535800020	Gas control valve (natural gas)
31.	535800020	Gas control valve (propane gas)
32.	535820033	RH Burner pipe (tap to elbow)
33.	535810021	RH Burner pipe (elbow to burner)
34.	535810022	Centre burner pipe
35.	535810023	LH burner pipe
36.	535810024	RH pilot pipe
37.	535810025	Centre pilot pipe
38.	535810026	LH pilot pipe