




I2FZP



I4FZP



I6FZP



A = GPL / LP gas / Gaz liquide / Flüssiggas  
 B = Gas metano / Natural gas / Gaz naturel / Erdgas

Pezzi/Pieces Pieces/Anzahl			Pos.	Validità dalla matricola Validité du numéro matricule Validity from serial number Gültigkeit ab der (Seriennummer)	Validità alla matricola Validity up to serial number Validité au numéro matricule Gültigkeit bis zur (Seriennummer)	Codice Code Artikel Nummer	Descrizione	Description	Description	Beschreibung
I2FZP	I4FZP	I6FZP								
2	4	6	1			X13200	Dado fissaggio iniettore	Injector fastening nut	Ecrou de fixation injecteur	Befestigungsmutter Einspritzung
1	2	3	2			1550Y63000	Griglia	Grid	Grille	Rost
1	2	4	3			V00300	Spartifiamma 4,0 kW	Flame spreader 4,0 kW	Diffuseur de flamme 4,0 kW	Flammenverteiler 4,0 kW
1	2	4	4			V00100	Corpo bruciatore 4,0 kW	Burner body 4,0 kW	Corps bruleur 4,0 kW	Brennerkörper 4,0 kW
1	2	2	5			V00400	Spartifiamma 7,8 kW	Flame spreader 7,8 kW	Diffuseur de flamme 7,8 kW	Flammenverteiler 7,8 kW
1	2	2	6			V00200	Corpo bruciatore 7,8 kW	Burner body 7,8 kW	Corps bruleur 7,8 kW	Brennerkörper 7,8 kW
1	2	4	7P			V01800	Coppa bruciatore 4,0 kW P	Scoop burner 4,0 kW P	Godet bruleur 4,0 kW P	Brennerschale 4,0 kW P
1	2	3	8			X13300	Termocoppia fuoco poster.	Rear ring thermocouple	Thermocouple feu poster.	Thermoelem. Hintere kochst.
1	2	3	9			X14200	Termocoppia fuoco anter.	Front ring thermocouple	Thermocouple feu anter.	Thermoelem. Vordere kochst.
1	2	2	10P			V01900	Coppa bruciatore 6 kW P	Cup burner 6 kW P	Coupelle bruler 6 kW P	Brennerkappe 6 kW P
1	2	4	11A			X33700	Iniettore gpl fuoco 4,0 kW	Ring lpg injector 4,0 kW	Injecteur gpl feu 4,0 kW	Gasdüse gpl kochst. 4,0 kW
1	2	4	11B			X34600	Iniettore metano fuoco 4,0 kW	Ring natural gas inject. 4,0 kW	Injecteur methane feu 4,0 kW	Gasdüse methan kochst. 4,0 kW
2	4	6	12			V01100	Porta iniettore	Injector-holder	Porte-injecteur	Düsenträger
1	2	2	13A			X34400	Iniettore 7,8 kW /GPL	LPG injector 7,8 kW	Injecteur gaz GPL 7,8 kW	Gasdüse GPL 7,8 kW
1	2	2	13B			X35700	Iniettore 7,8 kW/metano	Natural gas injector 7,8 kW	Injecteur gaz methane 7,8 kW	Gasdüse Methan 7,8 kW
2	4	6	14			X08100	Rubinetto fuoco	Gas ring cock	Robinet feu	Gashan kochstelle
1	2	4	15X			X11000	By pass 4,0 kW	By pass 4,0 kW	By pass 4,0 kW	By pass 4,0 kW
1	2	2	15Y			X04800	By pass 6 kW	By pass 6 kW	By pass 6 kW	By pass 6 kW
2	4	3	16A			X30000	Iniettore pilota/GPL	LPG injector	Injecteur gaz GPL	Gasdüse GPL
2	4	6	16B			X30300	Iniettore pilota/metano	Natural gas injector	Injecteur gaz methane	Gasdüse Methan
2	4	6	17			0000Y65103	Manopola per fuoco	Gas ring knob	Cle de commande pour feu	Drehknopf für kochstelle
2	4	6	18			V01500	Regolazione aria bruciatore	Burner air regulation	Règlage air bruler	Luftregelung Brenner
2	4	6	19			X14400	Pilota	Pilot	Veilleuse d'allumage	Zündflammenbrenner