


MAGIC SNACK 60

CUCINE / RANGES / HERDE / CUISINIÈRES / N° 0310

CF-62

CF-62EM CF-62ET CF-62EM/A CF-62ET/A

	1	2
Vedi Pagina See Page Siehe Seite Voir Page Ver Pagina	116	130




560002002M00P00

MAGIC SNACK 60

CUCINE / RANGES / HERDE / CUISINIÈRES / N° ≥0310


FORNO / OVEN / BACKOFEN / FOUR / CF-62

ELETTORICO MULTIFUNZIONE / MULTIFUNCTION ELECTRIC / MULTIFUNKTIONS
ELEKTRO / ELECTRIQUE A FONCTIONS MULTIPLES ≥0707



560003602M00P00

PC-E



Page	Pos	Code	Description
001		537002200	ELECTRICAL PLATE D.180 W1500 V230
001		537002100	ELECTRICAL PLATE D.145 W1000 V230
001		541015500	NEUTRAL SPACER 62
001		544060502	UPPER PLATE NEW PC-62E CF-62E
001		544041101	CONTROL PANEL CF-62E
001		537007600	TERMINAL BLOCK SINGLEPHASE 40A
001		544040901	SIDE RANGE CF-62
001		531008100	ADJUSTABLE LEG H9 CHROME
002		539024000	SIGN PLATE FOR OVEN SELECTOR
002		537019201	OVEN COMMUTATOR MULTIF.60+65
002		536013800	KNOB D.70 BLACK 6*5 WITH SPRING
002		539023301	ADHESIVE GRADUATED*EL.MULTIF.COMM.
002		537014100	WHITE WARNING LIGHT 250V
002		537014200	GREEN WARNING LIGHT 250V
002		539023900	SIGN PLATE FOR OVEN TEMPERATURE
002		537019101	THERMOSTAT MONOPHAS.050-320°C F.MF
002		539023800	SIGN PLATE FOR OVEN TIMER
002		537019300	TIMER FOR MULTIFUNCTION OVEN
002		537019301	
002		539023501	ADHESIVE GRAD.DISC *E.MULTIF.TERM.
002		539023400	ADHESIVE GRADUATED DISC F.KNOB
002		537006402	OVEN ELEMENT * 62 SUP. 2500W 230V
002		533095900	PIN FOR GRIDHOLDER SUPPORT CF 60
002		537006800	FAN 240V CF-62
002		537019000	CIRCULAR HEATING ELEMENT FOR OVEN
002		534018000	
002		536011402	OVEN GASKET CF-62
002		533084801	PANEL SPACER OF AIR DIFF.MAXI OVEN
002		537005400	OVEN BULB 15W 300°C
002		537007900	OVEN BULB-SOCKET
002		533079700	LOCK SPRING FOR BULB §3/§4
002		531012402	DOOR WHEEL HOLDER FOR MAXI OVEN
002		531037801	SUPPORT GRID OVEN NEW CF-62E
002		531012802	OVEN GRID CF-62E
002		537025001	OVEN HEATING EL.W1600 V230 62
002		531012502	COMPLETE OVEN DOOR 60*GLAS
002		536011102	
002		536021801	DOOR HANDLE SPACER FOR MAXI OVEN
002		536006502	OVEN DOOR HANDLE 60LINE AL.
002		531064500	EXTERNAL GLASS OVEN DOOR+FRAME*CF62
002		531007102	OVEN DOOR HINGE FOR 60LINE
003		537000300	COMMUTATOR 7 POSITIONS S.49 16A
003		536002100	KNOB 7 POSITIONS SNACK
003		537014100	WHITE WARNING LIGHT 250V