


# MAGIC SNACK 60

CUCINE / RANGES / HERDE / CUISINIÈRES / N° 20310  
CF-62

## CFC-62EM CFC-62ET

	1
Vedi Pagina See Page Siehe Seite Voir Page Ver Pàgina	116




# MAGIC SNACK 60

CUCINE / RANGES / HERDE / CUISINIÈRES / N° ≥0310

FORNO / OVEN / BACKOFEN / FOUR / CF-62

ELETTORICO MULTIFUNZIONE / MULTIFUNCTION ELECTRIC / MULTIFUNKTIONS  
ELEKTRO / ELECTRIQUE A FONCTIONS MULTIPLES ≥0707



560003602M00P00

Page	Pos	Code	Description
001		541042100	UPPER PLATE PCC-74E
001		537013300	CURRENT REGULATOR FOR ELEC. PLATE
001		537014100	WHITE WARNING LIGHT 250V
001		541015500	NEUTRAL SPACER 62
001		537021500	REGULATOR FOR EL.PLATE 2CIRC.230V
001		537015301	EL. PLATE PCC D.230 700+1400W 230V
001		536013500	KNOB 7 POSITIONS PCC-60E
001		537014501	EL. PLATE PCC-60 D.165 1200W 230V
001		536013900	KNOB 7 POSITIONS PCC-60E
001		537020001	REMAINING HEAT 4 PILOT LIGHTS UNIT
001		544041101	CONTROL PANEL CF-62E
001		537007600	TERMINAL BLOCK SINGLEPHASE 40A
001		544040901	SIDE RANGE CF-62
001		531008100	ADJUSTABLE LEG H9 CHROME
002		539024000	SIGN PLATE FOR OVEN SELECTOR
002		537019201	OVEN COMMUTATOR MULTIF.60+65
002		536013800	KNOB D.70 BLACK 6*5 WITH SPRING
002		539023301	ADHESIVE GRADUATED*EL.MULTIF.COMM.
002		537014100	WHITE WARNING LIGHT 250V
002		537014200	GREEN WARNING LIGHT 250V
002		539023900	SIGN PLATE FOR OVEN TEMPERATURE
002		537019101	THERMOSTAT MONOPHAS.050-320°C F.MF
002		539023800	SIGN PLATE FOR OVEN TIMER
002		537019300	TIMER FOR MULTIFUNCTION OVEN
002		537019301	
002		539023501	ADHESIVE GRAD.DISC *E.MULTIF.TERM.
002		539023400	ADHESIVE GRADUATED DISC F.KNOB
002		537006402	OVEN ELEMENT * 62 SUP. 2500W 230V
002		533095900	PIN FOR GRIDSHOLDER SUPPORT CF 60
002		537006800	FAN 240V CF-62
002		537019000	CIRCULAR HEATING ELEMENT FOR OVEN
002		534018000	
002		536011402	OVEN GASKET CF-62
002		533084801	PANEL SPACER OF AIR DIFF.MAXI OVEN
002		537005400	OVEN BULB 15W 300°C
002		537007900	OVEN BULB-SOCKET
002		533079700	LOCK SPRING FOR BULB §3/§4
002		531012402	DOOR WHEEL HOLDER FOR MAXI OVEN
002		531037801	SUPPORT GRID OVEN NEW CF-62E
002		531012802	OVEN GRID CF-62E
002		537025001	OVEN HEATING EL.W1600 V230 62
002		531012502	COMPLETE OVEN DOOR 60*GLAS
002		536011102	
002		536021801	DOOR HANDLE SPACER FOR MAXI OVEN
002		536006502	OVEN DOOR HANDLE 60LINE AL.
002		531064500	EXTERNAL GLASS OVEN DOOR+FRAME*CF62
002		531007102	OVEN DOOR HINGE FOR 60LINE