


MAGIC SNACK 60

SHINE KITCHEN

BC1/45 BC2/45 BC3/45 BC/45 BC/30



Page	Pos	Code	Description
001		544210800	
001		541041300	ROUNDED DRAWER BC3/45
001		533033100	HANDLE SPACER
001		536003400	SILVER HANDLE 60/SK
001		533088900	
001		544210700	
001		531007500	GUIDE-RAIL WHEEL D.25X10X22
001		536001900	WHEEL CAP
001		536003200	CHROME COVERHOLE §8
001		531008100	ADJUSTABLE LEG H9 CHROME
001		531034200	LHD TELESCOPIC GUIDE
001		534012900	LHD "Z" TELESCOPIC GUIDE DS50 L500
001		536000200	D.12 H.4 BUMPER
001		536003300	COVERHOLE §12
001		531034100	RHD TELESCOPIC GUIDE
001		534012800	RHD "Z" TELESCOPIC GUIDE DS50 L500