

**Kochgeräte  
Elektro Multibräter Serie 700**

Artikel-Nr. 137203, 137204  
(418031-371251XI, -371451XI)

---

**Ersatzteile**

---

## 8. Ersatzteile

**Aussenteile.....31**

**Innenteile.....33**

**Innenteile.....35**




## 8.1 Spannungscodes

Spannung	Spannungscodes
A	3/N/PE~400/230V 50Hz
B	~250V 16A 50Hz
C	3/N/PE~380/220V 50Hz
D	3/PE~200V 50-60Hz
F	2/PE 220-240V 50Hz
G	3/N/PE~415/240V 50Hz
H	3/PE~230V 50Hz
I	3/PE~220V 60Hz
J	3/PE~380 50Hz
K	3/PE~400V 50Hz
L	3/PE~415V 50Hz
M	3/PE~440V 60Hz
N	3/PE~460V 60Hz
O	3/PE~480V 60Hz
P	1/N/PE~220-240V 50Hz
R	2/PE~220-230V 60Hz
S	3/N/PE~400/230V 50Hz
T	3/PE~230V 60Hz
U	1/N/PE~100V 50-60Hz

## 8.2 Produktcodes

Produktcode	Ernennung
Modellcodes	
Typecodes	
400	137003
800	137004
Zubehörcodes	





---

ID	Typ	Spannung	Description	P-code
<b>Module:Aussenteile</b>				
10			Knebel	824710250X
20			Drehknopfdichtung	825110510
40			Knebel Hauptschalter	41824710230X
50			Weisses Lampe	6A038506
60			Grunes Lampe	826650050
70			Glas	6A039207
80			Turscharniere	2547860
90			Turscharniere	2547870
100			Fuss	826490142
160			Magnet	826900011

400 = 137003, 800 = 137004

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz




---

ID	Typ	Spannung	Description	P-code
<b>Module:Innenteile</b>				
130	400		Thermostat	826630123
130	800		Thermostat	826630191
140			Sicherheitshermostat	826630130
150	800		Fernschalter	826630300
160			Magnet	826900011
170			Deckel	821720761
180			Flussigkeitsauffangbecken	821530160
190			Hauptschalter	6A046700
70			Lampe	6A038506

400 = 137003, 800 = 137004

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz





---

ID	Typ	Spannung	Description	P-code
<b>Module:Innenteile</b>				
200			Auslaufrohr	2515010
210			Widerstand	826620241
220			Stopfen	2515000
170			Deckel	821720761
180			Flussigkeitsauffangbecken	821530160

400 = 137003, 800 = 137004

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz

