



SC176 SPARE PARTS LIST

NO.	CODE	NAME	MODEL	QTY	MATERIAL	REMARK
01	G350.24	DOWN HINGE		1		
02	SC176.02	WASHER		2		
03	SC176.03	BUSHING		2		
04	SC176.04	GLASS DOOR		1		
05	SC176.05	GASKET		1		
06	SC176.06	UP HINGE		1		
07	SC176.07	CONDENSER		1		
08	SC176.08	LAMP SIDE SUPPORT		2		
09	SC176.09	LNMP TOP SUPPORT		2		
10	G350.18	TOP LAMP	8W	1		
11	SC176.11	TOP BACK COVER		1		
12	SC176.23	TOP LAMP SUPPORT		1		
13	S900.34	CIRCLE FAN	SA1238A2	1		
14	SC176.12	FAN SUPPOR		1		
15	SC176.13	CONTROLLER	WPF7	1		
16	SC176.14	CONTROLLER PANEL		1		
17	SC176.15	KNOB		1		

18	SC176.18	LAMP COVER		1		
NO.	CODE	NAME	MODEL	QTY	MATERIAL	REMARK
20	S900.47	PLUG		1		
21	SC176.19	GRILL		1		
22	S900.40	WATER PAN		1		
23	S900.41	COMPRESSOR	OF1350A	1		
24	SC176.20	UNIT BOARD		1		
25	S900.48	JUNCTION BOX		1		
26	GN650TN.86	LOCK		1		
27	SC176.21	FRONT PANEL		1		
28	SC176.20	BODY		1		
29	G350.08	SHELF CLIP		16		
30	SC176.21	SUPPORT		4		
31	SC176.22	SHELF		4		
32	G350.06	FEET		4		
33	SC176.23	LAMP SWITCH		1		
34	SC176.10	LAMP COVER		1		