



**Snackgeräte  
Teller-Wärmeschrank**


Artikel-Nr. 271005  
(OTS-48)

---

**Explosionszeichnung / Ersatzteile**

---

# OTS-48



OTS – 48

	CODE		CODE		CODE		CODE
1	453500310	11	402591000	21	453500430		
2	453500320	12	502510140A	22	401040750		
3	402010000	13	453500040	23	453500140		
4	402085500	14	453500050	24	453500160		
5	502510110	15	453500170	25			
6	407502136	16	453500081	26			
7	453500100	17	407810500	27			
8	401500550	18	453500090				
9	402501100	19	453500080				
10	402595000	20	453500150				