


MAGIC PROF 65

CUCINE / RANGES / HERDE / CUISINIÈRES / N° ≥0309

CF...-8...

CF4-8ET CF4-8ETS

	1CF4-8ET	1CF4-8ETS	2	3
Vedi Pagina See Page Siehe Seite Voir Page Ver Pàgina	82	80	86	90




MAGIC PROF 65

CUCINE / RANGES / HERDE / CUISINIÈRES / N° ≥0309

FORNO / OVEN / BACKOFEN / FOUR

STATICO ELETTRICO / TRADITIONAL ELECTRIC / STATISCHER ELEKTRO /
ELECTRIQUE STATIQUE ≥0706




560003702M00P00

MAGIC PROF 65

CUCINE / RANGES / HERDE / CUISINIÈRES / N° ≥ 0309
FORNO / OVEN / BACKOFEN / FOUR

PORTE / DOORS / TÜREN / PORTES ≥ 0706


531009602



560025301M00P00


531012702

544015702



560025402M00P00

CF



Page	Pos	Code	Description
001		541070100	NEUTRAL SPACER 8
001		537002300	ELECTRICAL PLATE D.220 W2000 V230
001		544263500	RIGHT SIDE S.65
001		544257400	UPPER PLATE PC-8E
001		544293600	CONTROL PANEL CF4/CFC4-8ET
001		544302101	CONTROL PANEL CF4/CFC4-8ETS * NEW
001		539018900	INDEX FOR KNOB
001		539018100	ADHESIVE GRADUATED DISC FOR KNOB
001		537000300	COMMUTATOR 7 POSITIONS S.49 16A
001		544263600	LEFT SIDE S.65
001		537007700	TERMINAL BLOCK THREEPHASE 40A
001		57014100	
001		536013800	KNOB D.70 BLACK 6*5 WITH SPRING
002		539028000	SELECTOR SIGN PLATE FOR OVEN
002		539023800	SIGN PLATE FOR OVEN TIMER
002		539023900	SIGN PLATE FOR OVEN TEMPERATURE
002		537035600	OVEN COMMUTATOR * EL. 60+65LINES
002		536013800	KNOB D.70 BLACK 6*5 WITH SPRING
002		537019101	THERMOSTAT MONOPHAS.050-320°C F.MF
002		539007200	ADHESIVE GRADUATE F.MAXI-EL.STAT.OV
002		537014100	WHITE WARNING LIGHT 250V
002		537014200	GREEN WARNING LIGHT 250V
002		539023501	ADHESIVE GRAD.DISC *E.MULTIF.TERM.
002		539023400	ADHESIVE GRADUATED DISC F.KNOB
002		537006200	UPPER OVEN HEATING EL.1000+2000W
002		533095900	PIN FOR GRIDSHOLDER SUPPORT CF 60
002		531057800	RHD GRIDS HOLDER FOR MAXI-OVEN
002		534009100	GRILL PROTECTION CF-8/10
002		537005400	OVEN BULB 15W 300°C
002		537007900	OVEN BULB-SOCKET
002		533079700	LOCK SPRING FOR BULB §3/§4
002		536011301	OVEN GASKET CF-8/10 *FE*
002		531012402	DOOR WHEEL HOLDER FOR MAXI OVEN
002		531057900	LHD GRIDS HOLDER FOR MAXI-OVEN
002		531006701	MAXI OVEN GRID FOR S60/65
002		537006300	LOWER OVEN HEATING EL.W1750 230CF8/
002		537019300	TIMER FOR MULTIFUNCTION OVEN
002		537019301	
003		531009602	GLASS DOOR FOR MAXI OVEN OF 600LINE
003		536007102	
003		531064400	EXTERNAL GLASS MAXI OVEN DOOR+FRAME
003		536021801	DOOR HANDLE SPACER FOR MAXI OVEN
003		536006502	OVEN DOOR HANDLE 60LINE AL.
003		531007302	DOOR HINGE FOR MAXI OVEN 60.LINE
003		531012702	STAINLESS STEEL OVEN DOOR 60 LINE
003		544074703	S/S MAXI OVEN DOOR PANEL
004		544301600	RIGHT SIDE FOR 65 RANGE
004		544301500	LEFT SIDE FOR 65 RANGE
004		536005300	PLASTIC LED 2"