


IPERLOTUS 90

ELETRICO / ELECTRIC / ELEKTRO / ELECTRIQUE

FT..-94ET FT..-98ET FT..-94ETX FT..-98ETX



Page	Pos	Code	Description
001		544407300	RIGHT SIDE PANEL 90 LINE
001		532004100	FLUE GRID L=370 70LINE (RAF)
001		537012800	SAFETY THERMOSTAT 420°C THREEPHASE
001		544023901	SPATTLE FOR FRY-TOP
001		537000900	THERMOSTAT 50-320°C THREEPHASE
001		537001200	FIXING BRACKET FOR THERMOSTAT/COMM.
001		539018900	INDEX FOR KNOB
001		537000200	COMMUTATOR 1 POS. 3PHASE S.49 16A
001		536019700	BLACK KNOB §70 PIN §6*5
001		539018400	ADHESIVE GRADUATED DISC FOR KNOB
001		537014200	GREEN WARNING LIGHT 250V
001		537014100	WHITE WARNING LIGHT 250V
001		544413700	SPLASH GUARD FT-98
001		541104300	CONTROL PANEL FT-78E
001		541096400	DRIP TRAY FT S.70
001		537007700	TERMINAL BLOCK THREEPHASE 40A
001		544407400	LEFT SIDE PANEL 70 LINE
001		537025200	HEATING ELEMENT W2000 V230 FT 90
001		537038900	HEATING ELEMENT W2000 V230 FT 90
001		541123700	UPPER PLATE FTR-94ES
001		541124000	UPPER PLATE FTR-98E
001		544023800	
001		536005200	INOX LEG 2" 120-180 M10