

**MOINHO DE CAFÉ
MCF MC**

- > **REF.** 6.0.052.0018


- > **POTÊNCIA** 373w
POWER

- > **ROTAÇÃO POR MINUTO** 420
ROTATION PER MINUTE

- > **CAPACIDADE DA TREMONHA** 1,2Kg
HOPPER CAPACITY

- > **PRODUTIVIDADE** 18Kg/h
PRODUCTIVITY

- > **DIAMETRO DA MÓS** 49mm
GRINDERSTONE DIAMETER



MOINHO DE CAFÉ

MCF MC

01	>	5.0.052.2676	TAMPA DA TREMONHA Hopper cover	37	>	5.0.053.SEDP	PLACA ELECTRÓNICA Electronic board
02	>	5.0.052.2845	PROTEÇÃO DO IMAN SUPERIOR Upper magnet protection	38	>	5.0.053.1672	FREIO 8A Retention gasket 8A
03	>	5.0.052.3476	IMAN PARA TREMONHA PEQUENA Magnet for small hopper	39	>	5.0.053.5590	PERNO DO SATÉLITE Satellite pin
04	>	5.0.052.3499	IMAN PARA TREMONHA GRANDE Magnet for large hopper	40	>	5.0.053.5589	SUPORTE SATÉLITE Satellite support
05	>	5.0.052.2844	PROTEÇÃO DO IMAN INFERIOR Lower magnet protection	41	>	5.0.053.2800	SATÉLITE Satellite
06	>	5.0.052.2736	TREMONHA C/ IMAN Hopper with magnet	42	>	5.0.053.1674	FREIO 10A Retention gasket 10A
07	>	5.0.052.3352	FECHO TREMONHA Hopper lock	43	>	5.0.053.5591	PLANETÁRIO Planetary
08	>	5.0.052.2649	BOCAL P/TREMONHA CÓNICA Hopper-holding spout	44	>	5.0.053.1670	FREIO 15A Retention gasket 15A
09	>	5.0.052.2720	ANEL REGULAÇÃO MOAGEM Dial for spout	45	>	5.0.053.0824	RETENTOR 35X24X6 Sealing gasket
		5.0.052.2837	ANEL REGULAÇÃO MOAGEM Dial for spout	46	>	5.0.053.2524	ROLAMENTO 6202-2Z Bushing
10	>	5.0.052.2754	JUNTA MOTOR/DOSEADOR (NOVO MODELO) Motor/doser gasket (new model)	47	>	5.0.052.2740	PÉ Grinder foot
11	>	5.0.052.3154	SENSOR MAGNÉTICO Magnetic sensor				
12	>	5.0.053.2746	TAMPA DOSEADORA P/AUTOMÁTICO Automatic Doser cover				
13	>	5.0.052.3202	MICRO-INTERRUPTOR Micro switch				
14	>	5.0.052.2733	MEMBRANA DO DOSEADOR Doser membrane				
15	>	5.0.052.2753	BOTÃO MICRO INTERRUPTOR Micro switch knob				
16	>	5.0.053.3333	ANEL CROMADO P/AUTOMÁTICO Dial for automatic				
17	>	5.0.052.2652	ARO DEPÓSITO CAFÉ MOIDO Plexiglass ring				
18	>	5.0.052.2017	MOLA PERNO ESTRELA Mould spring				
19	>	5.0.052.3907	REGULADOR DE DOSES Dose adjustment knob				
20	>	5.0.052.5248	PERNO FIXO A ESTRELA Guide bar				
21	>	5.0.052.2727	ESTRELA SUPERIOR Upper doser star				
22	>	5.0.052.3321	LAMINA DOSEADORA Doser sheet				
23	>	5.0.052.2728	ESTRELA CENTRAL Star with ball				
24	>	5.0.052.2029	MOLA VEIO CENTRAL Central shaft spring				
25	>	5.0.052.2729	ESTRELA INFERIOR Lower doser star				
26	>	5.0.053.METD	ETIQUETA P/ DISPLAY CALCADOR ADEL Display label for Adel coffee tamper				
27	>	5.0.053.2878	TAMPA P/ CALCADOR ADEL Cover for Adel coffee tamper				
28	>	5.0.052.3332	CORPO DO DOSEADOR 3332 Painted doser case				
29	>	5.0.053.2880	PULSADOR P/ PLACA ADEL Adel plaque switch				
30	>	5.0.053.SEDL	PLACA ELECTRÓNICA CALCADOR ADEL Electronic board for Adel coffee tamper				
31	>	5.0.053.2881	ARO P/ CALCADOR ADEL Ring for Adel coffee tamper				
32	>	5.0.053.2882	CALCADOR ADEL Adel coffee tamper				
33	>	5.0.052.5129	VEIO CENTRAL Central shaft				
34	>	5.0.052.2632	BOCAL SAIDA CAFÉ Coffee discharger				
35	>	5.0.052.2868	PRATO RECUPERAÇÃO CAFÉ Coffee spill tray				
36	>	4.2.000.9236	INTERRUPTOR BIP. F 11.405L Grinder main On/Off switch				