



Kochgeräte Grillplatten Serie 700

Artikel-Nr. 133204, 133205, 133206, 133227,
133216, 133217, 133218, 133219, 133220, 133221, 133228
(418031-131250PXI, -136250 PXI, -131451 PXI, -136451PXI,
-531250 XI, 536250XI, - 532250XI, -531451XI, -532451XI, -534451XI,
-532250XI)

Ersatzteile

8. Ersatzteile

Aussenteile.....27

Innere Bestandteile.....29

8.1 Spannungscodes

Spannung	Spannungscodes
A	3/N/PE~400/230V 50Hz
B	~250V 16A 50Hz
C	3/N/PE~380/220V 50Hz
D	3/PE~200V 50-60Hz
F	2/PE 220-240V 50Hz
G	3/N/PE~415/240V 50Hz
H	3/PE~230V 50Hz
I	3/PE~220V 60Hz
J	3/PE~380 50Hz
K	3/PE~400V 50Hz
L	3/PE~415V 50Hz
M	3/PE~440V 60Hz
N	3/PE~460V 60Hz
O	3/PE~480V 60Hz
P	1/N/PE~220-240V 50Hz
R	2/PE~220-230V 60Hz
S	3/N/PE~400/230V 50Hz
T	3/PE~230V 60Hz
U	1/N/PE~100V 50-60Hz

8.2 Produktcodes

Produktcode	Ernennung
Typecodes	
400	133016
405	133017
410	133018
800	133019
810	133020
820	133021
400V	133004
405V	133005
800V	133006






Ersatzteile

ID	Typ	Description	P-code
Module: Aussenteile			
10		Fuss	826490142
20		Cassetto	41826161370
35	400E,400VE	Platte	41826470590
	410E	Platte	41826470650
	405E,405VE	Platte	41826470690
	800E,800VE	Platte	41826470700
	820E	Platte	41826470630
	810E	Platte	41826470660
40		Knebel	824710250X
41		Drehknopfdichtung	825110510
50		Lampe grun	826650050
55		Lampe	6A038506
60		Weisses glas	6A039207

400E=133016, 405E=133017, 410E=133018, 800E=133019, 810E=133020, 820E=133021, 400VE=133004,
405VE=133005, 800VE=133006

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz



Ersatzteile

ID	Typ	Description	P-code
Module:Innere Bestandteile			
70		Wideshtand 1266 W	41826620070
80		Sicherheitshermostat	826630130
90		Thermostat	826630123
100		Hauptschalter	6A046001

400E=133016, 405E=133017, 410E=133018, 800E=133019, 810E=133020, 820E=133021, 400VE=133004,
405VE=133005, 800VE=133006

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz