


*
E3R v.....
 INDICARE IL VOLTAGGIO
 INDICUER LA TENSION
 PLS GIVE VOLTAGE
 DIE SPANNUNG MITTELEN

Hz.....
 INDICARE LA FREQUENZA
 INDICUER LA FREQUENCE
 PLS GIVE FREQUENCY
 DIE FREQUENZ MITTELEN


COMPONENTI ELETTROVALVOLE
 COMPONENTS OF SOLENOID VALVES


COMPOSANTS DES ELECTROVANNES
 BESTANDTEILE DER MACHTVENTILE


TAB. N° 27-1





SOLO PER L'ITALIA
 SEULEMENT POUR L'ITALIE
 ONLY FOR ITALY
 NUR FÜR ITALIEN









SOLO PER IL TIPO BASIC
 SEULEMENT POUR TYPE BASIC
 ONLY FOR TYPE BASIC
 NUR FÜR TYP BASIC




SELECTRON


BASIC







404-930-002



①

①