


SNACK 60 ELETTRICO / SNACK 60 ELECTRIC / SNACK 60 ELEKTRO /
SNACK 60 ELECTRIQUE

PC-61EM PC-62EM PC-62ET



Page	Pos	Code	Description
001		541015400	NEUTRAL SPACER 61
001		537002200	ELECTRICAL PLATE D.180 W1500 V230
001		537002100	ELECTRICAL PLATE D.145 W1000 V230
001		544060400	UPPER PLATE PC-61E
001		544061900	RIGHT SIDE PANEL 60 LINE
001		544022500	CONTROL PANEL PC-1E
001		537014100	WHITE WARNING LIGHT 250V
001		536002100	KNOB 7 POSITIONS SNACK
001		537000300	COMMUTATOR 7 POSITIONS S.49 16A
001		533010300	ADJUSTABLE FOOT M10*20 D.23
001		544062000	LEFT SIDE PANEL 60 LINE
001		536006900	RUBBER CABLE GUIDE D.25MM.HOLE 16MM
001		537007600	TERMINAL BLOCK SINGLEPHASE 40A
001		536011800	HEXAGONAL LOCK NUT PG-13,5
001		537013800	CABLE SECURING CLAMP PG-13,5