
# Spare Parts catalogue



# WT 730 WTM
# WT 760 WTM
# WT 790 WTM

**Flight type dishwasher**

DOC. NO. **ST0 16 13-02**
EDITION 6 2003.12

# TABLE OF CONTENTS


| | | Page |
|---|---|---|
| • **Load section** | - L=900 | 4-7 |
| • **Gate** | | 8-9 |
| • **Washtanks** | - tank + plates | 10-11 |
| | - drain and wash system | 12-13 |
| | - heating | 14-15 |
| • **Final rinse** | - tank + plates | 16-17 |
| | - wash system | 18-21 |
| • **Water connections** | | 22-23 |
| • **Switch cabinet** | - electrical cabinet, integrated | 24-29 |
| | - internal electrical cabinet, remote control | 30-33 |
| | - external electrical cabinet, remote control | 34-37 |
| • **Drying tunnel L=1300** | - stand + plates | 38-39 |
| | - fan + drain | 40-41 |
| | - booster - steamheated machine | 42-43 |
| • **Energy saving device, ESD** | | 44-45 |
| • **Feeding** | | 46-47 |
| • **Unload section** | - L=1800 | 48-49 |
| • **Attachment element** | | 50-52 |





**ILLUSTRATION 21560**





**ILLUSTRATION 21561U**





**ILLUSTRATION 21562**





**ILLUSTRATION 21563**





**ILLUSTRATION 21564**





**ILLUSTRATION 21565**

C To Energy Saving Device (ESD)





**ILLUSTRATION 21566**





**ILLUSTRATION 215 67**





**ILLUSTRATION 215 80UW**





**ILLUSTRATION 215 82UW**





**ILLUSTRATION 216 18**





**ILLUSTRATION 216 19**





**ILLUSTRATION 216 13**





**ILLUSTRATION 216 14**





**ILLUSTRATION 216 15**

A Incoming cold water
B To the booster heater
C From the heat exchanger pump
D To the cleaning ramp
E Tank filling, hot water
F Pre-wash cooling, cold water





**ILLUSTRATION 216 16**





**ILLUSTRATION 214 86UW**





**ILLUSTRATION 216 17**