


Snackgeräte Elektro-Fritteusen

Artikel-Nr.
70244029 (FE8)

Explosionszeichnung / Ersatzteile

Bitte bei Ersatzteilbestellung immer Artikelnummer und Seriennummer mit angeben!

SPARE PART LIST / ESPLOSO FE-FC8-8R-88-88R



SPARE PART LIST / ESPLOSO FE-FC8-8R-88-88R

REF.	CODE CODICE	DESCRIPTION	DESCRIZIONE
1		Rear cover	Carter posteriore testata
2	R00110	Microswitch	Microinterruttore
3	R00109	Safety thermostat 240°C	Termostato sicurezza 240°C
4		Front cover	Carter testata
5	R00348	Switch knob & ring	Manopola e ghiera interruttore
6	R00264	Green light	Spia verde
7	R00202	Orange light	Spia arancione
8	R00265	Thermostat knob & ring	Manopola e ghiera termostato
9	R00209	Switch	Interruttore
10	R00041	Working thermostat 180°C	Termostato lavoro 180°C
11	R00266	Double bulbs spring	Molla bulbi doppia
12		Heating element cover	Carter resistenza
13	R00267	Capillary spring	Molla capillare
14	R00108	Heating element 3250 W	Resistenza 3250 W
15	R00309	Lid knob	Pomolo coperchio
16		Lid	Coperchio
17	R00212	Basket	Cestello
18		Chassis FE-FC8	Carcassa FE-FC8
18	R00149	Chassis FE-FC88	Carcassa FE-FC88
18		Chassis FE-FC8R	Carcassa FE-FC8R
18		Chassis FE-FC88R	Carcassa FE-FC88R
19	R00603	Foot	Piedino
20	R00310	Handle	Maniglia
21	R00545	Basin FE-FC8-88	Vasca FE-FC8-88
21		Basin FE-FC8R-88R	Vasca FE-FC8R-88R
22	R00268	Electric cable	Cavo elettrico
23	R00645	Contactora (only FC)	Teleruttore (solo FC)
24	R00208	Tap	Rubinetto