



7.8 kW
4.0 kW

C2FZ
T2FZ
C2FZP
T2FZP

4.0 kW
7.8 kW

7.8 kW
4.0 kW

7.8 kW
7.8 kW

7.8 kW
7.8 kW

C4FZ
T4FZ
C4FZP
T4FZP

C4FZSP

4.0 kW
4.0 kW

7.8 kW
4.0 kW

4.0 kW
4.0 kW

C6FZ
T6FZ
C6FZP
T6FZP

C6FZ - C6FZP
T6FZ - T6FZP

C4FZ - C4FZP
C4FZSP
T4FZ - T4FZP

C2FZ - C2FZP
T2FZ - T2FZP

A = GPL / LP gas / Gaz liquefie / Flüssiggas (2H)
B = Gas metano / Natural gas / Gaz naturel / Erdgas (3+)



3E05-002

C2FZ - C4FZ - C6FZ
C2FZP - C4FZP - C6FZP - C4FZSP
T2FZ - T4FZ - T6FZ
T2FZP - T4FZP - T6FZP

Pezzi/Pieces Pieces/Anzahl							Pos.	Validità dalla matricola Validity from serial number Validité du numéro matricule Gültigkeit ab der (Seriennummer)	Validità alla matricola Validity up to serial number Validité au numéro matricule Gültigkeit bis zur (Seriennummer)	Codice Code Artikel Nummer	Descrizione	Description	Description	Beschreibung
C2FZ - T2FZ*	C4FZ - T4FZ*	C6FZ - T6FZ*	C3FZP - T2FZP*	C4FZP - T4FZP*	C6FZP - T6FZP*	C4FZSP								
			2	4	6	4	1		X13200	Dado fissaggio iniettore	Injector fastening nut	Ecrou de fixation injecteur	Befestigungsmutter Einspritzung	
1	2	3	1	2	3	2	2		1550Y63000	Griglia	Grid	Grille	Rost	
1	2	4	1	2	4		3		V00300	Spartifiamma 4,0 kW	Flame spreader 4,0 kW	Diffuseur de flamme 4,0 kW	Flammenverteiler 4,0 kW	
1	2	4	1	2	4		4		V00100	Corpo bruciatore 4,0 kW	Burner body 4,0 kW	Corps bruleur 4,0 kW	Brennerkörper 4,0 kW	
1	2	2	1	2	2	4	5		V00400	Spartifiamma 7,8 kW	Flame spreader 7,8 kW	Diffuseur de flamme 7,8 kW	Flammenverteiler 7,8 kW	
1	2	2	1	2	2	4	6		V00200	Corpo bruciatore 7,8 kW	Burner body 7,8 kW	Corps bruleur 7,8 kW	Brennerkörper 7,8 kW	
			1	2	4		7P		V01800	Coppa bruciatore 4,0 kW	Scoop burner 4,0 kW	Godet bruleur 4,0 kW	Brennerschale 4,0 kW	
1	2	4					7N		V02000	Coppa bruciatore 4,0 kW S/P	Scoop burner 4,0 kW W/P	Godet bruleur 4,0 kW S/P	Brennerschale 4,0 kW O/P	
			1	2	3	2	8		X13300	Termocoppia fuoco posteriore	Rear ring thermocouple	Thermocouple feu poster.	Thermoelem. Hintere kochst.	
			1	2	3	2	9		X14200	Termocoppia fuoco anteriore	Front ring thermocouple	Thermocouple feu anter.	Thermoel. Vordere kochst.	
			1	2	2	4	10P		V01900	Coppa bruciatore 6,0/7,8/9,5 kW	Scoop burner 6,0/7,8/9,5 kW	Godet bruleur 6,0/7,8/9,5 kW	Brennerschale 6,0/7,8/9,5 kW	
1	2	2					10N		V02100	Coppa bruciatore 7,8 kW S/P	Scoop burner 7,8 kW W/P	Godet bruleur 7,8 kW S/P	Brennerschale 7,8 kW O/P	
1	2	4	1	2	4		11A		X33700	Iniettore GPL fuoco	Ring LPG injector	Injecteur GPL feu	Gasdüse GPL kochst.	
1	2	4	1	2	4		11B		X34600	Iniettore metano fuoco	Ring natural gas injector	Injecteur methane feu	Gasdüse methan kochst.	
2	4	6	2	4	6	4	12		0600V01100	Porta iniettore	Injector-holder	Porte-injecteur	Düsenräger	
1	2	2	1	2	2	4	13A		X34400	Iniettore GPL fuoco	Ring LPG injector	Injecteur GPL feu	Gasdüse GPL kochst.	
1	2	2	1	2	2	4	13B		X35700	Iniettore metano fuoco	Ring natural gas injector	Injecteur methane feu	Gasdüse methan kochst.	
2	4	6					14		X08000	Rubinetto fuoco	Gas ring cock	Robinet feu	Gashan kochstelle	
			2	4	6	4	15		X08100	Rubinetto fuoco	Gas ring cock	Robinet feu	Gashan kochstelle	
1	2	4	1	2	4		16X		X11000	By Pass 0,45	By Pass 0,45	By Pass 0,45	By Pass 0,45	
1	2	2	1	2	2	4	16Y		X04800	By Pass 0,75	By Pass 0,75	By Pass 0,75	By Pass 0,75	
			2	4	6	4	17A		X30000	Iniettore pilota GPL	LPG pilot injector	Injecteur pilote GPL	Pilotdüse GPL	
			2	4	6	4	17B		X30300	Iniettore pilota metano	Natural gas pilot injector	Injecteur pilote methane	Pilotdüse methan	
2	4	6					18N		0000Y65101	Manopola per fuoco	Gas ring knob	Cle de commande pour feu	Drehknopf für kochstelle	
			2	4	6	4	18P		0000Y65103	Manopola per fuoco	Gas ring knob	Cle de commande pour feu	Drehknopf für kochstelle	
1	2	3	1	3	2	2	19		1550Y63500	Griglietta scarico fumi	Smoke discharge grid	Grille évacuation des fumées	Rauchblassgitter	
2	4	6	2	4	6	4	20		0600V01500	Regolazione aria bruciatore	Burner air regulation	Réglage air bruler	Luftregelung Brenner	
			2	4	6	4	21		X14400	Pilota	Pilot	Veilleuse d'allumage	Zündflammenbrenner	
4/0*	4/0*	4/0*	4/0*	4/0*	4/0*	4/0*	22C		X61000	Piedino	Foot	Pied	Fuss	
0/4*	0/4*	0/4*	0/4*	0/4*	0/4*	0/4*	22T		M06400	Piedino	Foot	Pied	Fuss	
2	4	6					23		0600V00900	Supporto	Support	Appui	Unterstützung	
2	4	6					24		X14500	Candeletta	Ignition plug	Bougie	Glühkerze	
2	4	6					25		M02100	Piezo elettrico	Piezo-electric ignition	Piezo électrique	Piezoelektrischer Zünder	
1	2	3					26		X13900	Termocoppia fuoco posteriore	Rear ring thermocouple	Thermocouple feu poster.	Thermoelem. Hintere kochst.	
1	2	3					27		X14100	Termocoppia fuoco anteriore	Front ring thermocouple	Thermocouple feu anter.	Thermoel. Vordere kochst.	
			2	4	6	4	28		X13100	Bicono	Bicone	Bicône	Bicône	