


IPERLOTUS 90 TOP

ELETTRICO / ELECTRIC / ELEKTRO / ELECTRIQUE


PCT-94ET PCT-98ET PCT-912ET PCT-916ET PCQT-94ET PCQT-98ET PCQT-912ET PCQT-916ET

	1
Vedi Pagina See Page Siehe Seite Voir Page Ver Pagina	172



560064400M00P00

PCT-E



560023700M00P00

Page	Pos	Code	Description
001		541116900	UPPER PLATE PCQ-98E CFQ4-98ET
001		541116600	UPPER PLATE PC-98E CF4-98ET
001		541104000	CONTROL PANEL PC-78E
001		544446800	
001		533010500	LEG M10*25 D.40
001		537007700	TERMINAL BLOCK THREEPHASE 40A
001		544446900	
001		532004100	FLUE GRID L=370 70LINE (RAF)
001		537017400	ELECTRICAL PLATE D.300 W3500 V230
001		537017100	PLATE 300X300 W4000 V230
002		539018900	INDEX FOR KNOB
002		536019700	BLACK KNOB §70 PIN §6*5
002		539018100	ADHESIVE GRADUATED DISC FOR KNOB
002		537014100	WHITE WARNING LIGHT 250V
002		537027700	COMMUTATOR 7 POSITIONS S.43 32A