



NGWR 7-85, 10-85W1S1, 15-85W2, 16-85W2S1, 18-85W2S2, 22-85W3, 24-85W3S2

Nayati Gas Wok Range


Spare part list

SOUP BURNER


Burner Components




Number	B-Nr.	Description	Part No.
1		Burner Head NS 9001	GS.4030
2		Burner Base NS 9001	GS.4023
3		Plug 3/8" x 1/4" for Burner	GS.4232
4		Fixing Bush 1 1/4"	GS.2851



Number	B-Nr.	Description	Part No.
1		Air Chamber Mixing Jumbo Burner	GS.4357
2		Air Chamber Plate Jumbo Burner	GS.4358
3		Air Chamber Pipe 1"	GS.2826
4		Air Chamber Bush 1 1/2"	GS.2825



Number	B-Nr.	Description	Part No.
1		Tension spring	GS.1456
2		Safety Gas Cock	GS.3875
3		Gas knob Ø8 mm	PD.4052A
4		Ring label api model	PD.4055L
5		V-ring 38	PD.1522
6		Adhesive for ring knob	PD.4056




Number	B-Nr.	Description	Part No.
1		Pilot Burner / Bunsen Pilot 3F/3H	GS.3851
2		Thermocouple M9 x 1/1000 Mm	GS.3890

Nozzles



Number	B-Nr.	Description	Part No.
1		Injector Burner dia. 1.60 (G30/G31=28-30/37mbar)	GS.282E
1		Injector Burner dia. 1.40 (G30/G31=50 mbar)	GS.282C
1		Injector Burner dia. 2.35 (G20=20 mbar)	GS.282H
2		Injector Pilot dia. 0.20 (for G30/G31)	GC.1001
2		Injector Pilot dia. 0.35 (for G20)	GS.3828

Accessories



Number	B-Nr.	Description	Part No.
1		Grid Ø 275 mm	GS.2720



NGWR 7-85, 10-85W1S1, 15-85W2, 16-85W2S1, 18-85W2S2, 22-85W3, 24-85W3S2


Nayati Gas Wok Range

WOK BURNER


Burner Components



Number	B-Nr.	Description	Part No.
1		Burner Cap f/ Jumbo Burner	GS.2020
2		Burner Base f/ Jumbo Burner	GS.4353
3		Fixing Screw f/ Burner Cap	GS.1329
4		Socket Screw	GS.1317
5		Pin f/ Burner Base	GS.4700



Number	B-Nr.	Description	Part No.
1		Air Chamber Mixing Jumbo Burner	GS.4357
2		Air Chamber Plate Jumbo Burner	GS.4358
3		Air Chamber Pipe 1"	GS.2826
4		Air Chamber Bush 1 1/2"	GS.2825



Number	B-Nr.	Description	Part No.
1		Tension spring	GS.1456
2		Fixing Bush 1 1/4"	GS.2851
3		Gas knob Ø8 mm	PD.4052A
4		Ring label api model	PD.4055L
5		V-ring 38	PD.1522
6		Adhesive for ring knob	PD.4056

Spare part list




Number	B-Nr.	Description	Part No.
1		Pilot Burner / Bunsen Pilot 3F/3H	GS.3851
2		Thermocouple M9 x 1/1000 mm	GS.3890

Nozzles



Number	B-Nr.	Description	Part No.
1		Injector Burner dia. 1.60 (G30/G31=28-30/37mbar)	GS.282E
1		Injector Burner dia. 1.40 (G30/G31=50 mbar)	GS.282C
1		Injector Burner dia. 2.35 (G20=20 mbar)	GS.282H
2		Injector Pilot dia. 0.20 (for G30/G31)	GC.1001
2		Injector Pilot dia. 0.35 (for G20)	GS.3828

Accessories



Number	B-Nr.	Description	Part No.
1		Seal f/Wok Grill dia. 451 x 403 mm	GS.2227
2		Kwali ring 402 x 330 mm	PD.3009
3		Leg 3 " for NGWR	GC.9203



NGWR 7-85, 10-85W1S1, 15-85W2, 16-85W2S1, 18-85W2S2, 22-85W3, 24-85W3S2


Nayati Gas Wok Range

Spare part list

Gas Connection




Number	B-Nr.	Description	Part No.
1		Elbow Cooper to Female 3/4 "	GS.2351
2		Straight Coupler male to male	GS.1071
3		Safety Control Device	GS.3713
4		Elbow 3/4 "	GS.1161



Number	B-Nr.	Description	Part No.
1		Gas Valve 3/4 "	GS.2006
2		Joint f/ Shaft Handle	GS.4326
3		Screw f/ Joint Shaft	GS.1336
4		Bush f/ Shaft Handle	GS.4325



Number	B-Nr.	Description	Part No.
1		Handle Valve Assy	GS.8006S
2		Ball Knob	GS.2014
3		Handle Shaft	GS.4226



Number	B-Nr.	Description	Part No.
1		Pilot Valve 1/4 "	GS.2004
2		Elbow 1/4 "	GS.1159
3		Straight Joint 1/4 x 1/8 x 1/4	GS.4513
4		Brass Joint 1/4 x 1/8	GS.1250

Water Components



Number	B-Nr.	Description	Part No.
1		Faucet Stop Tap	GS.2305
2		Water Outflow	GS.8046S



Number	B-Nr.	Description	Part No.
3		Water Sprayer Nozzle	GS.3846