


# IPERLOTUS 90

ELETTRICO / ELECTRIC / ELEKTRO / ELECTRIQUE


**TP-98ET**

	1
Vedi Pagina See Page Siehe Seite Voir Page Ver Página	134



560074100M00P00

**TP-ET**



560074700M00P00.

Page	Pos	Code	Description
001		532004100	FLUE GRID L=370 70LINE (RAF)
001		539018900	INDEX FOR KNOB
001		536019700	BLACK KNOB §70 PIN §6*5
001		537037600	COMMUTATOR 4 POS.3PHASE S.43 32A
001		539008800	ADHESIVE GRAD.DISC 4POS.CPT-ET RED
001		537014100	WHITE WARNING LIGHT 250V
001		544407400	LEFT SIDE PANEL 70 LINE
001		541104000	CONTROL PANEL PC-78E
001		537007700	TERMINAL BLOCK THREEPHASE 40A
001		537000900	THERMOSTAT 50-320°C THREEPHASE
001		544407300	RIGHT SIDE PANEL 90 LINE
001		536005200	INOX LEG 2" 120-180 M10
002		541157601	
002		546015501	
002		541157701	UPPER PLATE TP-98E
002		537034300	HEATING EL. 250X250 3400W230V
002		533111500	COIL SPRING INTØ7X18XØFILO1 H=10