


BR-62ET



Page	Pos	Code	Description
001		541015500	NEUTRAL SPACER 62
001		541028400	TANK BR-62
001		533033300	TANK HANDLE BR-62
001		537015100	HEATING ELEMENT 2000W 230V BR
001		533045600	GASKET D.12XD.16X1,5
001		546000100	SQUARE BRAID OF INSULATING MATERIAL
001		533037600	LOCK SPRING FOR BULB
001		546000200	SQUARE BRAID OF INSULATING MATERIAL
001		541028500	UPPER PLATE BR-62E
001		544061900	RIGHT SIDE PANEL 60 LINE
001		537012800	SAFETY THERMOSTAT 420°C THREEPHASE
001		537001200	FIXING BRACKET FOR THERMOSTAT/COMM.
001		544069900	CONTROL PANEL BS-62EM
001		537014200	GREEN WARNING LIGHT 250V
001		537014100	WHITE WARNING LIGHT 250V
001		536002300	KNOB 50-300°C THREEPHASE SNACK
001		537000200	COMMUTATOR 1 POS. 3PHASE S.49 16A
001		537000900	THERMOSTAT 50-320°C THREEPHASE
001		533010300	ADJUSTABLE FOOT M10*20 D.23
001		544062000	LEFT SIDE PANEL 60 LINE
001		537007700	TERMINAL BLOCK THREEPHASE 40A
001		537014000	CABLE SECURING CLAMP PG-21
001		536012000	HEXAGONAL LOCK NUT PG-21
001		536006900	RUBBER CABLE GUIDE D.25MM.HOLE 16MM