


SOLO PER PORTE
DOORS ONLY
NUR FUER TUER
SEULEMENTO POUR PORTES
SOLO PUERTAS


# Modello Typ Model Modele Modelo

| | | 6RMAA<br>6RMAB<br>6RMAM<br>RM1A<br>6RMAZ | 6RMA2A<br>6RMA2B<br>6RMA2M<br>RM1A/2<br>6RMA2Z | 6RMBA<br>6RMBB<br>6RMBM<br>RM1B<br>6RMBZ | 6RMB2A<br>6RMB2B<br>6RMB2M<br>RM1B/2<br>6RMB2Z | 6RMB4A<br>6RMB4B<br>6RMB4M<br>RM1B/4<br>6RM4BZ | 6RMCA<br>6RMCB<br>6RMCM<br>RM1C<br>6RMCZ | 6RMC2A<br>6RMC2B<br>6RMC2M<br>RM1C/2<br>6RMC2Z | 6RMC4A<br>6RMC4B<br>6RMC4M<br>RM1C/4<br>6RMC4Z | 6RMC6A<br>6RMC6B<br>6RMC6M<br>RM1C/6<br>6RMC6Z |
|---|---|---|---|---|---|---|---|---|---|---|
| Num.cassetti<br>Schublad<br>Drawers<br>Tiroirs<br>Gabetas | 1/2 | - | 2 | - | 2 | 4 | - | 2 | 4 | 6 |
| | 1/3 | - | - | - | - | - | - | - | - | - |
| | 2/3 | - | - | - | - | - | - | - | - | - |


1/2




1/3




2/3



## Modello Typ Model Modele Modelo

| | | 6RMAA<br>6RMAB<br>6RMAM<br>RM1A<br>6RMAZ | 6RMA2A<br>6RMA2B<br>6RMA2M<br>RM1A/2<br>6RMA2Z | 6RMBA<br>6RMBB<br>6RMBM<br>RM1B<br>6RMBZ | 6RMB2A<br>6RMB2B<br>6RMB2M<br>RM1B/2<br>6RMB2Z | 6RMB4A<br>6RMB4B<br>6RMB4M<br>RM1B/4<br>6RM4BZ | 6RMCA<br>6RMCB<br>6RMCM<br>RM1C<br>6RMCZ | 6RMC2A<br>6RMC2B<br>6RMC2M<br>RM1C/2<br>6RMC2Z | 6RMC4A<br>6RMC4B<br>6RMC4M<br>RM1C/4<br>6RMC4Z | 6RMC6A<br>6RMC6B<br>6RMC6M<br>RM1C/6<br>6RMC6Z |
|---|---|---|---|---|---|---|---|---|---|---|
| Porte<br>Türen<br>Doors<br>Portes<br>Puertas | DX | 1 | 1 | 2 | 2 | 1 | 3 | 3 | 2 | 1 |
| | SX | 1 | - | 1 | - | - | 1 | - | - | - |

