# Service part catalogue

## iCombi® as of 03/2020 201 - 20 x 1/1 Gastronorm


### G21SJ2408XXXXXXX




10/5/2024
1NAC230 V 50/60Hz

© Copyright by RATIONAL Technical Service
All Rights reserved


# Overview



# Overview

Pos. 1 Control panel **4**
Pos. 2 Electrical installation **6**
Pos. 3 ClimaPlus **12**
Pos. 4 Steam generator **14**
Pos. 5 Hot air heating **17**
Pos. 6 Motor and fan wheel **23**
Pos. 7 Interior cabinet **25**
Pos. 8 Door **27**
Pos. 9 Exterior cabinet **33**
Pos. 10 Water **37**
Pos. 11 CleanJet + Care **39**
Pos. 12 Gas parts **41**
Pos. 13 Standard accessory **43**
Pos. 20 Repair and retrofit kit **55**


# Pos. 1 Control panel



# Pos. 1 Control panel

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 87.01.535S | Control panel insert with touch/TFT *RAT* | 1 |
| 2 | 16.03.342P | Sealing f. panel insert | 1 |
| 3 | 42.00.357P | Display *TFT* | 1 |
| 4 | 16.03.747P | Fixing display / pcb | 1 |
| 6 | 42.00.251P | Control pcb (w/o SD-Card) | 1 |
| 8 | 42.00.359P | Micro SD card | 1 |
| 9 | 42.00.346P | Sensor on / off | 1 |
| 10 | 40.06.760P | Cable control pcb - capacitive switch | 1 |
| 11 | 40.06.044P | USB socket with cable | 1 |
| 12 | 40.06.410P | Interface cable LAN 2m | 1 |
| 13 | 16.03.756P | Dial f. pulse generator | 1 |
| 14 | 40.06.037P | Pulse generator | 1 |
| 15 | 16.04.606P | Cover f. control pcb w. gasket | 1 |
| 16 | 16.04.204S | On-Off sensor support | 1 |
| 17 | 16.03.748P | Metal cramp f. panel insert | 6 |
| 18 | 16.03.749P | Hook for parking position | 2 |
| 21 | 40.06.569P | Cable CPU - TFT | 1 |
| 23 | 16.03.701P | Sealing block LAN | 1 |


# Pos. 2 Electrical installation



# Pos. 2 Electrical installation

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | | Electrical installation | 1 |
| 9 | 40.06.355P | Cooling fan | 1 |
| 10 | 87.01.619S | Air shaft cpl. | 1 |
| 12 | 87.01.741S | Interface USB | 1 |
| 13 | 40.05.509P | Interface LAN IPX6 | 1 |
| 14 | 40.06.410P | Interface cable LAN 2m | 1 |
| 15 | 40.06.681S | Mounting support power transformer | 1 |
| 16 | 10.01.208P | Hex screw M8x80 A2 | 1 |
| 18 | 40.06.878P | Cable holder | 12 |
| 22 | 40.00.320S | Cable gland M20x1.5 | 1 |
| 23 | 40.00.320S | Cable gland M20x1.5 | 1 |
| 24 | 40.04.495P | Cable connection M25 ø5mm *divisible* | 1 |
| 100 | 40.06.066P | Cable control harness | 1 |
| 105 | 40.06.242P | Cable, circulation pump | 1 |
| 106 | 40.06.245P | Cable, sewage pump | 1 |
| 107 | 40.06.248P | Cable SC pump | 1 |
| 108 | 40.06.251P | Cable, Care pump | 1 |
| 109 | 40.06.718P | Cable, interior light W57 *door lighting* | 1 |
| 112 | 40.06.752P | Power supply cable 3x2,5 $mm^2$ 3m | 1 |
| 114 | 40.07.149P | Bus cable 2.08m | 1 |
| 115 | 40.05.858P | Bus cable 1.08m | 1 |
| 116 | 40.07.147P | Bus cable 1.96m | 1 |
| 117 | 40.05.858P | Bus cable 1.08m | 1 |
| 118 | 40.05.858P | Bus cable 1.08m | 1 |
| 121 | 40.05.858P | Bus cable 1.08m | 1 |
| 126 | 40.07.451P | Cable hot air probe - eSTB | 1 |
| 127 | 40.07.452P | Cable, steam probe - eSTB | 1 |


# Pos. 1 Electrical installation



# Pos. 1 Electrical installation

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 40.06.637P | Electrical mounting plate | 1 |
| 2 | 10.00.709P | Hex nut M6 w. locking | 1 |
| 3 | 42.00.286P | Power supply | 1 |
| 5 | 40.01.358P | Rocker switch 1 pole | 1 |
| 9 | 40.03.756P | Fixing clip f. pcb | 1 |
| 11 | 40.05.919P | IO-module | 1 |
| 14 | 10.02.008P | Rivet with screw | 1 |
| 15 | 40.03.756P | Fixing clip f. pcb | 1 |
| 16 | 40.06.116S | Mounting support for pump pcb | 1 |
| 17 | 10.02.008P | Rivet with screw | 1 |
| 18 | 42.00.273P | Pump pcb | 1 |
| 28 | 40.06.767P | Fuse 4A *Typ 5HT 4-R* | 1 |


# Pos. 10 Air shaft cpl.



# Pos. 10 Air shaft cpl.

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 40.05.654P | Air inlet filter cpl. | 1 |
| 2 | 40.07.257P | Loudspeaker K 64 WP FR | 1 |


# Pos. 3 ClimaPlus



# Pos. 3 ClimaPlus

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 40.06.801P | Pressure sensor Huba 5 mbar | 1 |
| 2 | 40.05.702P | Mounting device f. pressure sensor | 1 |
| 4 | 22.01.495P | Hose set f. humidity control | 1 |
| 5 | 40.06.214P | Vent cover | 1 |
| 6 | 40.06.570P | Ventilation at top | 1 |
| 7 | 22.01.402P | Humidity control cpl. | 1 |
| 8 | 10.01.694P | O-ring for humidity control | 4 |
| 9 | 22.01.468P | Drain hose for humidity control, top | 1 |
| 10 | 2066.0527P | Hose clamp ø14mm | 4 |
| 11 | 22.01.385P | Air inlet pipe | 1 |
| 12 | 22.01.456P | Vent cover, left | 1 |
| 13 | 22.01.402P | Humidity control cpl. | 1 |
| 14 | 2066.0527P | Hose clamp ø14mm | 2 |
| 21 | 22.01.402P | Humidity control cpl. | 1 |

# Pos. 4 Steam generator




# Pos. 4 Steam generator

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 72.00.492P | V Clamp 50mm right | 1 |
| 2 | 87.01.626S | Kit Steam generator insolated | 1 |
| 3 | 44.02.200P | Gasket SC pump | 1 |
| 4 | 44.02.179S | Pump housing | 1 |
| 5 | 56.01.631P | O-ring for pump | 1 |
| 6 | 56.01.024P | Emptying pump | 1 |
| 7 | 44.02.287P | Emergency drainage hose | 1 |
| 8 | 10.01.707P | Locking ring 25mm | 1 |
| 9 | 10.01.707P | Locking ring 25mm | 1 |
| 10 | 44.02.873S | Supply hose safety armature | 1 |
| 11 | 44.02.221S | Drain hose steam generator | 1 |
| 12 | 10.01.707P | Locking ring 25mm | 1 |
| 13 | 10.01.707P | Locking ring 25mm | 1 |
| 14 | 87.01.548S | Safety device / water supply for steam generator | 1 |
| 16 | 50.02.121P | Hose, water supply, steam generator | 1 |
| 17 | 2066.0205P | Hose clamp 8-16x9 mm SW 7mm | 1 |
| 18 | 44.02.232P | Drain hose, safety device | 1 |
| 19 | 44.01.505P | Grommet Ø12x8,2 | 1 |
| 20 | 10.01.703P | Locking ring 16 mm | 1 |
| 21 | 44.02.497S | Molded hose with level electrode | 1 |
| 22 | 2066.0518P | Hose clamp 30mm | 2 |
| 23 | 70.01.336S | Burner steam gen. kit | 1 |
| 24 | 10.01.065P | Hex nut M5 | 1 |
| 25 | 72.00.408P | Gasket f. burner carrier | 1 |
| 29 | 40.06.131P | Temperature sensor eSTB 240mm *S* | 1 |
| 30 | 72.00.077P | Insulation f. burner steam gen. | 1 |
| 31 | 70.01.250S | Ignition electrode kit for steam generator | 1 |
| 32 | 70.01.258P | Gasket f. ignition electrode | 1 |
| 33 | 10.01.065P | Hex nut M5 | 2 |
| 34 | 10.01.065P | Hex nut M5 | 5 |

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 35 | 72.00.505P | Fixing plate steam generator thermostat | 1 |
| 36 | 40.06.721P | Thermocouple steam generator *B5* | 1 |


# Pos. 5 Hot air heating



# Pos. 5 Hot air heating

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1.1 | 74.01.054S | Hot air heat exchanger top | 1 |
| 1.2 | 74.01.057S | Hot air heat exchanger below | 1 |
| 2 | 74.01.124P | Gasket hot air heat exchanger/interior cabinet | 4 |
| 3 | 74.01.125P | Mating flange heat exchanger | 2 |
| 4 | 10.01.065P | Hex nut M5 | 10 |
| 5 | 10.01.065P | Hex nut M5 | 16 |
| 6 | 50.02.004P | Nozzle f. moistening | 1 |
| 7 | 50.02.005P | Union nut | 1 |
| 8 | 50.02.006P | Plastic pipe PEEK | 1 |
| 10 | 87.01.656S | Burner hot air | 1 |
| 11 | 87.01.657S | Burner hot air | 1 |
| 12 | 74.00.296P | Gasket f. heat exchanger below | 4 |


# Pos. 10 Burner hot air



# Pos. 10 Burner hot air

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 87.02.006S | Ignitionelectrode, hot air 350mm | 1 |
| 2 | 74.00.290P | Gasket electrode hot air | 1 |
| 3 | 10.00.696P | Allen screw M4x6 w. Precoat 85 | 4 |
| 4 | 87.02.010S | Earth electrode, hot air | 1 |


# Pos. 11 Burner hot air



# Pos. 11 Burner hot air

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 87.02.007S | Ignitionelectrode, hot air 960mm | 1 |
| 2 | 74.00.290P | Gasket electrode hot air | 1 |
| 3 | 10.00.696P | Allen screw M4x6 w. Precoat 85 | 4 |
| 4 | 87.02.010S | Earth electrode, hot air | 1 |


# Pos. 6 Motor and fan wheel



# Pos. 6 Motor and fan wheel

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1.1 | 87.01.558S | Fan motor | 1 |
| 1.2 | 87.01.558S | Fan motor | 1 |
| 1.3 | 87.01.558S | Fan motor | 1 |
| 2.1 | 42.00.276P | Motor control for fan motor | 1 |
| 2.2 | 42.00.276P | Motor control for fan motor | 1 |
| 2.3 | 42.00.276P | Motor control for fan motor | 1 |
| 3 | 20.02.807P | Isolation for mounting plate for motor | 3 |
| 6 | 10.00.709P | Hex nut M6 w. locking | 12 |
| 7 | 22.01.423P | Mounting support f. gasket flange | 3 |
| 8 | 22.01.425P | Graphit seal for gasket flange | 3 |
| 9 | 22.00.985P | Motor shaft gasket D15 | 3 |
| 10 | 22.01.427P | Flange f. motor shaft gasket | 3 |
| 11 | 10.01.065P | Hex nut M5 | 9 |
| 12 | 22.01.151S | Fan wheel | 3 |
| 13 | 1308.0162P | Washer A8,4 | 3 |
| 14 | 10.00.936P | Hex screw M8x20 | 3 |


# Pos. 7 Interior cabinet



# Pos. 7 Interior cabinet

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 22.01.349P | Air baffle | 1 |
| 2 | 40.06.112S | Temperature sensor eSTB *HA* | 1 |
| 3 | 40.06.684P | Safety temperature limiter | 1 |
| 4 | 40.06.053P | Fixing device for safety temperature limiter | 1 |
| 5 | 10.00.515P | Rivet 3,2x8 A2/NSF | 2 |
| 6 | 40.06.098P | Shielding for core temperature sensor | 1 |
| 7 | 10.01.076P | Cap nut M5*A2 | 1 |
| 8 | 40.06.802P | Thermocouple interior cabinet B1 | 1 |
| 9 | 40.05.489P | Shielding for interior cabinet sensor | 1 |
| 10 | 10.01.076P | Cap nut M5*A2 | 2 |
| 11 | 40.06.792S | Thermocouple humidity *B4* | 1 |
| 12 | 10.00.087P | Clamp strap f. sensor | 1 |
| 13 | 10.01.065P | Hex nut M5 | 1 |
| 14 | 40.06.810P | Core temperature probe | 1 |
| 15 | 1315.0104P | Copper washer 16x20x1,5 | 1 |
| 16 | 10.01.751P | Hex nut M16 DIN934 A2 | 1 |
| 17 | 56.01.491P | Outlet sieve | 1 |
| 18 | 20.00.398P | Door gasket | 1 |
| 22 | 40.06.892P | Thermocouple interior cabinet B9 | 1 |
| 23 | 40.05.489P | Shielding for interior cabinet sensor | 1 |
| 24 | 10.01.076P | Cap nut M5*A2 | 2 |


# Pos. 8 Door



# Pos. 8 Door

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 24.04.111S | Door | 1 |
| 2 | 24.04.065P | Door handle RATIONAL | 1 |
| 3 | 24.04.244S | Door lock | 1 |
| 4 | 10.01.776P | Pan head screw Torx T20 M4x12 | 2 |
| 5 | 10.00.090P | Cap f. Torx T30 | 1 |
| 7 | 10.00.697P | Hex screw M5x10 w. precoat 85 | 2 |
| 8 | 24.01.351P | Door catch | 1 |
| 9 | 10.00.936P | Hex screw M8x20 | 2 |
| 10 | 2001.0109P | Compression spring | 1 |
| 11 | 24.03.040P | Door bolt | 1 |
| 12 | 10.01.880P | Ornamental screw M8x25 | 1 |
| 13 | 24.04.245P | Door bolt | 1 |
| 14 | 10.00.099S | Hex screw M8x12 | 1 |
| 17 | 12.02.605P | Cap for door mounting support bottom | 1 |
| 18 | 16.04.110P | Cover for door mounting support | 1 |
| 21 | 24.05.002P | Stop spacer | 1 |
| 22 | 87.01.810S | Spacer plate door catch | 1 |
| 23 | 24.02.263P | Cover for door latch | 1 |


# Pos. 1 Door



# Pos. 1 Door

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 24.04.903S | Glass pane bundle | 1 |
| 4 | 24.04.219P | Door setting bolt | 1 |
| 5 | 10.00.904P | Rivet B4x8 | 2 |
| 7 | 24.04.471S | Drain gutter (incl. door magnet) | 1 |
| 8 | 1604.0161P | Rivet 4x6 CNS | 1 |
| 9 | 24.04.212S | Bracket right f. door floor model | 1 |
| 10 | 10.02.008P | Rivet with screw | 1 |
| 15 | 24.03.057P | Abrasion protection for glide socket | 1 |
| 16 | 24.03.787S | Fixing bracket kit for interior glass pane | 2 |
| 17 | 10.02.416P | Rivet Ø4x8, A2 | 2 |
| 18 | 24.03.062P | Cover cap for door | 1 |
| 19 | 87.01.578S | LED bar | 6 |
| 20 | 87.01.586S | LED optics | 6 |
| 21 | 24.05.458P | Plastic spreader rivet | 12 |
| 24 | 24.01.259P | Plastic buffer 8,1mm for door | 5 |
| 26 | 24.04.231S | Pre heat mechanism f. door cpl. | 1 |
| 101 | 87.01.595S | Cable, interior light W40 *door lighting* | 1 |


# Pos. 26 Pre heat mechanism f. door cpl.



# Pos. 26 Pre heat mechanism f. door cpl.

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 24.04.468S | Gasket support | 1 |
| 2 | 24.05.615P | Gasket glass pane/trolly | 1 |


# Pos. 9 Exterior cabinet



# Pos. 9 Exterior cabinet

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | | Exterior cabinet | 1 |
| 2 | 10.01.755P | Countersunk screw M5x25 A2 | 1 |
| 3 | 1206.0120P | Tooth lock washer A6,4 | 1 |
| 4 | 40.06.380P | Door switch | 1 |
| 5 | 16.00.384S | Bracket for door contact switch | 1 |
| 7 | 10.00.103P | EJOT PT-screw KA 3.5x10 | 1 |
| 8 | 40.06.214P | Vent cover | 1 |
| 9 | 16.03.729P | Gasket f. breather tube d=117.3mm | 1 |
| 10 | 56.01.430P | Tulip for handshower | 1 |
| 12 | 10.00.357P | Plug | 2 |
| 14 | 40.05.657P | Air inlet filter cpl. | 1 |
| 15 | 40.05.654P | Air inlet filter cpl. | 1 |
| 19 | 2039.0111P | Foot adjustable, metal, 40 x 40 | 4 |
| 20 | 60.75.895 | Holder for handle mobile oven rack type 20-1/1, 20-2/1 | 1 |
| 21 | 12.02.617S | Crossbar below | 1 |
| 22 | 56.01.639P | Mounting frame for Care container | 1 |
| 23 | 10.01.983P | Plug | 2 |


# Pos. 1 Exterior cabinet



# Pos. 1 Exterior cabinet

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 16.03.440P | Top cover | 1 |
| 2 | 1003.2265P | Countersunk self tapping screw 4,2x16 | 10 |
| 3 | 1104.0820P | Snap nut 4,2mm | 10 |
| 4 | 16.04.081P | Side panel right | 1 |
| 5 | 16.04.088P | Back panel | 1 |
| 8 | 16.03.438P | Side panel left | 1 |
| 9 | 10.01.755P | Countersunk screw M5x25 A2 | 2 |
| 11 | 16.03.688P | Front panel | 1 |
| 13 | 16.03.433P | Crossbar top | 1 |


# Pos. 10 Water



# Pos. 10 Water

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 54.01.929P | Ventilation pipe | 1 |
| 2 | 10.01.667P | Hose clamp 122mm | 1 |
| 3 | 54.01.650S | Silicone form piece, venting pipe + hose clamp | 1 |
| 4 | 10.01.667P | Hose clamp 122mm | 1 |
| 5 | 2067.0709P | Hose for water supply 2500mm | 1 |
| 6 | 50.00.086P | Locking plate f. water distribution | 1 |
| 7 | 50.02.012P | Solenoid valve fivefold with flowmeter | 1 |
| 9 | 50.00.085P | Retractor locking spring | 1 |
| 10 | 52.00.135S | Connect. hose f. hand shower roll guide | 1 |
| 11 | 50.00.085P | Retractor locking spring | 1 |
| 12 | 52.00.099P | Hand shower roll guide | 1 |
| 14 | 50.00.156P | Clamp f. hand shower roll guide | 1 |
| 15 | 52.00.127S | Hand shower black | 1 |
| 16 | 54.01.861S | Inspection lid, B2 | 1 |
| 17 | 54.01.168P | Gasket f. inspection lid | 1 |
| 26 | 50.02.201P | Supply hose for moistening | 1 |
| 27 | 2066.0205P | Hose clamp 8-16x9 mm SW 7mm | 4 |
| 31 | 50.00.554P | O-ring for hand shower 11x2mm | 2 |


# Pos. 11 CleanJet + Care



# Pos. 11 CleanJet + Care

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 56.00.952P | Drawer Care container | 1 |
| 2 | 56.01.466P | Care container with pump | 1 |
| 3 | 50.02.135P | Supply hose for "Care box" | 1 |
| 4 | 56.01.028P | Care Pump | 1 |
| 5 | 56.01.631P | O-ring for pump | 1 |
| 6 | 10.01.703P | Locking ring 16 mm | 1 |
| 7 | 56.01.508S | Care hose | 1 |
| 8 | 10.01.703P | Locking ring 16 mm | 1 |
| 17 | 56.01.461P | Gasket DN60 | 1 |
| 18 | 56.01.370P | Cleaning box | 1 |
| 21 | 56.01.017P | Drain pump Cleaning box | 1 |
| 22 | 56.01.631P | O-ring for pump | 1 |
| 23 | 56.01.020P | Recirculation pump | 1 |
| 24 | 56.01.631P | O-ring for pump | 1 |
| 25 | 2066.0521P | Hose clamp 27mm | 1 |
| 26 | 56.01.624S | CleanJet hose | 1 |
| 27 | 2066.0521P | Hose clamp 27mm | 1 |
| 28 | 56.01.979P | Pipe elbow with hose clamps | 1 |
| 29 | 2066.0527P | Hose clamp ø14mm | 1 |
| 30 | 87.01.636S | Cover for pump | 1 |
| 31 | 56.01.499P | Emergency overflow-tube | 1 |


# Pos. 12 Gas parts



# Pos. 12 Gas parts

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 70.01.209S | Automatic ignition controller | 1 |
| 2 | 10.02.008P | Rivet with screw | 1 |
| 3 | 70.01.074P | Burner pipe | 1 |
| 4 | 70.01.148P | Gasket f. blower burner | 3 |
| 5 | 10.01.747P | Hex screw M5x19 Torx T20 | 2 |
| 6 | 70.01.200P | Gas blower / gas valve kit, steam | 1 |
| 8 | 87.01.839S | Gas valve LK2 | 1 |
| 9 | 10.01.902P | Truss head screw Torx M5X12 T25 | 2 |
| 10 | 70.01.622P | Gasket corrugated hose | 3 |
| 11 | 70.01.268P | Connection compensation tube | 1 |
| 12 | 10.01.747P | Hex screw M5x19 Torx T20 | 4 |
| 13 | 70.01.673S | Gas blower / gas valve kit, hot air | 1 |
| 14 | 87.01.838S | Gas valve LK1 | 2 |
| 15 | 10.01.902P | Truss head screw Torx M5X12 T25 | 4 |
| 16 | 70.01.673S | Gas blower / gas valve kit, hot air | 1 |
| 17 | 70.01.609S | Gas connection manifold | 1 |
| 18 | 10.01.892P | Hex screw M5x20 Torx T20 | 2 |
| 19 | 70.00.188P | Hose fitting 3/4"-3/4" | 1 |
| 20 | 70.01.333P | Air supply, hot air | 1 |
| 21 | 70.01.332P | Air supply, hot air, top | 1 |
| 22 | 70.01.330P | Air supply, steam | 1 |
| 24 | 70.01.165P | Air hose adapter straight DN50 | 1 |
| 25 | 70.01.168P | Air hose adapter 90° DN40 | 2 |
| 100 | 87.01.739S | Wire set earth - ignition electrode | 1 |


# Pos. 13 Standard accessory



# Pos. 13 Standard accessory

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 60.71.022 | Positioning support for core sensor | 1 |
| 3 | 60.21.331 | Mobile oven rack type 20-1/1, | 1 |
| 4 | 60.75.326 | Condensation breaker | 1 |
| 7 | | Internal fat drain floor unit | 1 |
| 8 | | VarioSmoker | 1 |
| 10 | | Heat shield | 1 |
| 11 | | Flow guard | 1 |
| 13 | 87.01.757 | Memory-Stick USB *iCombi Pro & iCombi Classic* | 1 |


# Pos. 3 Mobile oven rack type 20-1/1,



# Pos. 3 Mobile oven rack type 20-1/1,

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 60.75.468P | Drain plug with chain for trolly | 1 |
| 2 | 60.74.681P | Castor with brake ø125mm | 2 |
| 3 | 60.74.680P | Castor without brake ø125mm | 2 |
| 4 | 60.21.296P | Handle for mobile oven rack | 1 |
| 5 | 60.75.895 | Holder for handle mobile oven rack type 20-1/1, 20-2/1 | 1 |
| 6 | 14.01.113S | Retrofit kit drip tray trolly 201 | 1 |
| 7 | 60.21.295P | Drip collector | 1 |
| 8 | 60.22.462P | Drain groove left for trolly | 1 |
| 9 | 60.22.463P | Drain groove right for trolly | 1 |
| 10 | 87.00.652 | Retrofit kit for slide piece | 1 |


# Pos. 7 Internal fat drain floor unit



# Pos. 7 Internal fat drain floor unit

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 60.76.409P | End cap for Internal fat drain | 1 |
| 2 | 60.74.564P | Gasket for int. fat drain | 1 |
| 3 | 56.00.874P | Gasket wastewater | 1 |
| 4 | 60.72.729P | Ball valve DN32 (1 1/4") | 1 |
| 5 | 60.72.609P | Drain pipe, bayonet with handle | 1 |
| 6 | 60.75.103P | Grease collector trolly 201 | 1 |
| 7 | 6013.1146P | Tray, 1/1 GN, 150 mm deep, high grade steel rustproof | 1 |
| 8 | 60.73.061P | Lid for tray, GN1/1 | 1 |


# Pos. 8 VarioSmoker



# Pos. 8 VarioSmoker

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 60.75.368P | Power supply for VarioSmoker *US* | 1 |
| 1 | 60.75.372P | Power supply for VarioSmoker *EU* | 1 |
| 1 | 60.75.374P | Power supply for VarioSmoker *UK* | 1 |
| 1 | 60.75.376P | Power supply for VarioSmoker *AU, NZ* | 1 |
| 1 | 60.75.378P | Power supply for VarioSmoker *CH* | 1 |
| 1 | 60.75.386P | Power supply for VarioSmoker *BRA* | 1 |
| 1 | 60.77.643P | Power supply for VarioSmoker *ARG* | 1 |
| 2 | 60.76.115S | Mounting device kit for VarioSmoker | 1 |
| 3 | 60.76.691P | Smoking box for VarioSmoker | 1 |
| 4 | 40.06.837P | Interface cable USB VarioSmoker | 1 |


# Pos. 10 Heat shield



# Pos. 10 Heat shield

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 60.75.825P | heat shield holder top | 1 |
| 2 | 60.75.833P | holder heat shield bottom | 1 |


# Pos. 11 Flow guard



# Pos. 11 Flow guard

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 70.01.500P | Ventilation pipe extension | 1 |
| 2 | 70.01.593P | Exhaust pipe (Draft diverter) | 1 |
| 3 | 70.01.373P | Exhaust pipe (Draft diverter) | 1 |
| 4 | 40.04.158P | Safety temperature limiter 103°C | 1 |
| 5 | 40.07.250S | Cable draft diverter B13 | 1 |

# Pos. 20 Repair and retrofit kit



# Pos. 20 Repair and retrofit kit

| Pos. | Part no. | Description | Qty. |
|---|---|---|---|
| 1 | 87.01.866S | Retrofit kit *Collision protection* | 1 |
| 4 | 87.01.815S | Retrofit kit safety door latch | 1 |
| 5 | 87.01.895S | Door arrester | 1 |
| 6 | 60.76.876 | Extension set for USB core temperature probe | 1 |
| 7 | 87.01.916S | Conversion kit iCombi w/o hand shower | 1 |
| 8 | 60.77.082 | Second water connection for filling the hand shower. | 1 |
| 10 | 87.01.897 | Retrofit kit waste water piping DN90 | 1 |
| 13 | 87.01.996S | Door arrester service kit | 1 |
| 14 | 14.01.113S | Retrofit kit drip tray trolly 201 | 1 |
| 16 | 40.07.586S | LED optics HD | 1 |
| 17 | 87.01.816S | Retrofit kit 4-fold relay | 1 |