


BR-6ET



Page	Pos	Code	Description
001		541070000	NEUTRAL SPACER 6
001		541028400	TANK BR-62
001		533033300	TANK HANDLE BR-62
001		537015100	HEATING ELEMENT 2000W 230V BR
001		537016200	HEATING ELEMENT 2000W 440V BR 65
001		533045600	GASKET D.12XD.16X1,5
001		546000100	SQUARE BRAID OF INSULATING MATERIAL
001		533037600	LOCK SPRING FOR BULB
001		541063600	UPPER PLATE BR-6E
001		546000200	SQUARE BRAID OF INSULATING MATERIAL
001		544263500	RIGHT SIDE S.65
001		537012800	SAFETY THERMOSTAT 420°C THREEPHASE
001		537017700	TRANSFORMER 440V/100V 10VA
001		544260900	CONTROL PANEL BR-6E
001		537017500	GREEN WARNING LIGHT LOW BUD 110V
001		537014200	GREEN WARNING LIGHT 250V
001		537014100	WHITE WARNING LIGHT 250V
001		537017600	WHITE WARNING LIGHT LOW BUD 110V
001		539018400	ADHESIVE GRADUATED DISC FOR KNOB
001		536013800	KNOB D.70 BLACK 6*5 WITH SPRING
001		537001200	FIXING BRACKET FOR THERMOSTAT/COMM.
001		537000900	THERMOSTAT 50-320°C THREEPHASE
001		537000200	COMMUTATOR 1 POS. 3PHASE S.49 16A
001		539018900	INDEX FOR KNOB
001		533010300	ADJUSTABLE FOOT M10*20 D.23
001		544263600	LEFT SIDE S.65
001		536011900	HEXAGONAL LOCK NUT PG-16
001		537013900	CABLE SECURING CLAMP PG-16
001		537007700	TERMINAL BLOCK THREEPHASE 40A